

PASSENGER CARRYING COACHING STOCK [Dean]**FIRST CLASS SALOON****SALOON**

Lot: 804 Diagram: G.31 Built: 1896 Builder: Swindon Bogied Design: Dean

Converted to Civil Engineer's Saloon in 1941.

231 8231 9035 80971 **Pontypool & Blaenavon Railway**

Lot: 840 Diagram: G.4 Built: 1897 Builder: Swindon Bogied Design: Dean

233 8233 9002 **Steam - Museum of The G.W.R., Swindon** Body only remains on u/f of BR MK 1 BSK 34626**234** 8234 9003 **Railholiday, St.Germans Station, Cornwall** Body only remains on u/f of BR MK 1 BSK 34832 (745282)**FIRST CLASS SLEEPING CAR****SLF**

Lot: 787 Diagram: J.5 Built: 1897 Builder: Swindon Bogied Design: Dean

Eight berths. Restored with underframe from GWR BCK 6912 - 079133.

242 8242 9038 **West Somerset Railway****DIRECTOR'S SALOON****SALOON**

Lot: 745 Diagram: G.3 Built: 1894 Builder: Swindon Bogied Design: Dean

Seats: 24F

Converted to Civil Engineer's Saloon in 1940.

249 8249 9045 80978 **South Devon Railway****FIRST CLASS RESTAURANT (with Kitchen)****RFK**

Lot: 801 Diagram: H.2 Built: 1896 Builder: Swindon Bogied Design: Dean

Seats: 16F

250 8250 9501 **Railholiday, St.Germans Station, Cornwall** Body only remains on u/f of SR BTK 3204**LUGGAGE COMPOSITE [non-gangwayed]****LC**

Lot: 206 Diagram: E.11 Built: 1882 Builder: Swindon Bogied Design: Dean

Seats: ??F,??T

660 6660 **Erwood Station Craft Centre & Museum, Powys** Body only remains**DYNAMOMETER CAR****DYNAMOMETER**

Lot: 293 Built: 1901 Builder: Swindon Bogied Design: Dean

Built under Wagon Lot 293

790 7 **South Devon Railway****TRI-COMPOSITE (slip coach)****TRI-COMPOSITE**

Lot: 890 Diagram: F.12 Built: 1898 Builder: Swindon Bogied Design: Dean

1091 7091 **Railholiday, St.Germans Station, Cornwall** Body only remains on replica u/f**THIRD [non-gangwayed]****T**

Lot: 1038 Diagram: C.22 Built: 1903 Builder: Swindon Bogied Design: Dean

1357 DW14571 **Didcot Railway Centre****COMPOSITE RESTAURANT (with Kitchen)****RCK**

Lot: 1010 Diagram: H.7 Built: 1902 Builder: Swindon Bogied Design: Dean

Seats: ??F,??T

Restored with underframe from GWR TK 3655.

1580 9520 **Didcot Railway Centre****THIRD [non-gangwayed]****T**

Lot: 962 Diagram: C.10 Built: 1901 Builder: Swindon Bogied Design: Dean

1941 DW14198 **Didcot Railway Centre**

PASSENGER CARRYING COACHING STOCK [Churchward, Collett, Hawksworth]

CORRIDOR THIRD

TK

Lot: 1623 Diagram: C.77 Built: 1940 Builder: Swindon Bogied Design: Collett Seats: 64T

Used as Internal User at Swindon Works

536 079152 **Didcot Railway Centre**

BRAKE OPEN THIRD

BTO

Lot: 1644 Diagram: D.130 Built: 1940 Builder: Swindon Bogied Design: Collett Seats: 40T

650 **Severn Valley Railway**

CORRIDOR THIRD

TK

Lot: 1691 Diagram: C.82 Built: 1948 Builder: Swindon Bogied Design: Hawksworth Seats: 64T

796 converted to a Dynamometer Car in 1961

796 ADW150192 **West Coast Railway Company, Carnforth**
829 **Severn Valley Railway**

Lot: 1593 Diagram: C.77 Built: 1938 Builder: Swindon Bogied Design: Collett Seats: 64T

Used as Internal Users at Swindon Works

1086 079154 **Severn Valley Railway**
1087 079158 **Severn Valley Railway**
1111 079159 **Didcot Railway Centre**
1116 079157 **Severn Valley Railway**
1146 079153 **Severn Valley Railway**

OPEN THIRD

TO

Lot: 1575 Diagram: C.74 Built: 1937 Builder: Swindon Bogied Design: Collett Seats: 64T

1285 **South Devon Railway**
1289 **Didcot Railway Centre**
1295 **South Devon Railway**

BRAKE CORRIDOR THIRD

BTK

Lot: 1594 Diagram: D.127 Built: 1938 Builder: Swindon Bogied Design: Collett Seats: 32T

Used as Internal User at Newton Abbot

1649 079170 **South Devon Railway**

CORRIDOR THIRD

TK

Lot: 1720 Diagram: C.82 Built: 1949 Builder: Swindon Bogied Design: Hawksworth Seats: 64T

2119 **Severn Valley Railway**

BRAKE CORRIDOR THIRD

BTK

Lot: 1732 Diagram: D.133 Built: 1950 Builder: Swindon Bogied Design: Hawksworth Seats: 32T

2180, 2216, 2225, 2232 & 2233 converted to CCE Staff & Dormitory Coaches in 1967/68

2180 DW150405 **South Devon Railway**
2202 **Didcot Railway Centre**
2216 DW150402 **Llangollen Railway**
2225 DW150392 **Cholsey & Wallingford Railway**
2232 DW150397 **Didcot Railway Centre**
2233 DW150401 **Severn Valley Railway**

Lot: 1744 Diagram: D.133 Built: 1951 Builder: Swindon Bogied Design: Hawksworth Seats: 32T

Converted to CCE Staff & Dormitory Coach in 1967

2242 DW150391 **Severn Valley Railway**

Lot: 1174 Diagram: D.46 Built: 1911 Builder: Swindon Bogied Design: Churchward Seats: 32T

Converted to Track Recording Coach in 1930

2360 DW139 **Barry Tourist Railway** 'Whitewash Coach'

Lot: 1180 Diagram: D.47 Built: 1911 Builder: Swindon Bogied Design: Churchward Seats: 32T

Converted to BTU Tool Van in 1955

2370 ADW309 **The Station Kitchen, West Bay, Dorset**

CORRIDOR THIRD

TK

Lot: 1167 Diagram: C.30 Built: 1910 Builder: Swindon Bogied Design: Churchward Seats: 64T

2426 converted to Camping Coach in 1952. 2434 converted to Staff & Dormitory Coach in 1956.

2426 9918 **Severn Valley Railway**
2434 DW150038 **Bodmin Steam Railway**

Lot: 1172 Diagram: C.31 Built: 1911 Builder: Swindon Bogied Design: Churchward Seats: 64T

Converted to BTU Staff Coach in 1956

2447	ADW150019		Doldwold Caravan Park, near Rhayader, Powys			
Lot: 1234	Diagram: C.32	Built: 1914	Builder: Swindon	Bogied	Design: Churchward	Seats: 64T
Converted to Camping Coaches in 1957/58						
2573	9879		West Somerset Railway		'CAROL'	
2578	9889		West Somerset Railway			
Lot: 1098	Diagram: C.24	Built: 1905	Builder: Swindon	Bogied	Design: Churchward	Seats: 72T
Used as Internal User at Newquay						
3299	079002		Didcot Railway Centre			
Lot: 1286	Diagram: C.32	Built: 1921	Builder: Swindon	Bogied	Design: Churchward	Seats: 64T
Rebuild of 3939, lot 1246 of 1915. Converted to Camping Coach in 1958.						
3631	9880		West Somerset Railway		'FLORENCE'	
Lot: 1289	Diagram: C.31	Built: 1921	Builder: Swindon	Bogied	Design: Churchward	Seats: 64T
Rebuild of 24xx, lot 11xx of 1910. Converted to Camping Coach in 1957.						
3639	9887		West Somerset Railway			
Lot: 1295	Diagram: C.35	Built: 1921	Builder: Swindon	Bogied	Design: Churchward	Seats: 64T
Rebuild of 3xxx, lot 12xx of 1917. Converted to Camping Coach in 1957.						
3665	9886		West Somerset Railway		'BERYL'	
Lot: 1313	Diagram: C.35	Built: 1922	Builder: Swindon	Bogied	Design: Churchward	Seats: 64T
Rebuild of 3xxx, lot 12xx of 1917. Converted to Camping Coach in 1957.						
3668	9888		Gwendraeth Valley Railway, Coed Bach, nr Kidwelly			
BRAKE THIRD [non-gangwayed]						BT
Lot: 1275	Diagram: D.62	Built: 1921	Builder: Swindon	Bogied	Design: Churchward	Seats: 60T
3755			Didcot Railway Centre			
3756			Didcot Railway Centre			
CORRIDOR THIRD						TK
Lot: 1269	Diagram: C.32	Built: 1920	Builder: Swindon	Bogied	Design: Churchward	Seats: 64T
Converted to Camping Coaches in 1958						
3885	3385	9882	West Somerset Railway		'HILDA'	
3898	9884		Swindon & Cricklade Railway		'FREDA'	
Lot: 1246	Diagram: C.32	Built: 1915	Builder: Swindon	Bogied	Design: Churchward	Seats: 64T
3917 converted to a Camping Coach in 1958. 3930 converted to CCE Staff & Dormitory Coach in 1956.						
3917	9883		Llangollen Railway		Numbered 3719 'GRACE'	
3930	DW150011		Severn Valley Railway			
Lot: 1256	Diagram: C.35	Built: 1919	Builder: Swindon	Bogied	Design: Churchward	Seats: 64T
Converted to Camping Coaches in 1957/58						
3963	9885		Didcot Railway Centre		'ALICE'	
3980	9881		West Somerset Railway		'ELSIE'	
Lot: 1352	Diagram: C.54	Built: 1925	Builder: Swindon	Bogied	Design: Collett	Seats: 64T
Converted to S&T Dormitory Coaches in 1959. KDW150205 subsequently used as Internal User at Westbourne Park.						
4546	KDW150205	060903	West Somerset Railway			
4553	KDW150207		Didcot Railway Centre			
Lot: 1369	Diagram: C.54	Built: 1926	Builder: Swindon	Bogied	Design: Collett	Seats: 64T
Converted to S&T Dormitory Coaches in 1959. KDW150206 subsequently used as Internal User at St.Austell Goods Yard and Exeter Red Cow Crossing.						
4777	KDW150206	060907	Honeybourne Airfield Industrial Estate			
4786	KDW150208		Severn Valley Railway			
Lot: 1372	Diagram: C.54	Built: 1927	Builder: Swindon	Bogied	Design: Collett	Seats: 64T
Converted to S & T Dormitory Coach in 1959.						
4872	KDW150209		South Devon Railway			
Lot: 1383	Diagram: C.54	Built: 1928	Builder: Swindon	Bogied	Design: Collett	Seats: 64T
5043 converted to a BTU Staff Coach in 1963. 5085 converted to a S&T Dormitory Coach in 1959.						
5043	ADW150301		Severn Valley Railway			
5085	KDW150200		Didcot Railway Centre			
BRAKE CORRIDOR THIRD						BTK
Lot: 1384	Diagram: D.95	Built: 1928	Builder: Swindon	Bogied	Design: Collett	Seats: 32T
Converted to a CCE Staff & Tool Coaches in 1959.						
5102	DW150234		Llangollen Railway			
5131	DW150246		West Somerset Railway			

BRAKE THIRD [non-gangwayed]							BT
Lot: 1493	Diagram: D.117	Built: 1934	Builder: Swindon	Bogied	Design: Collett	Seats: 50T	
Used as Internal User at Newport Docks							
5500	071343	Railway Support Services, Rye Farm, Wishaw					
Lot: 1392	Diagram: D.101	Built: 1928	Builder: Swindon	Bogied	Design: Collett	Seats: 50T	
Converted to BTU Staff Coach in 1962							
5539	DW150328	Railway Support Services, Rye Farm, Wishaw					
BRAKE CORRIDOR THIRD							BTK
Lot: 1490	Diagram: D.116	Built: 1933	Builder: Swindon	Bogied	Design: Collett	Seats: 32T	
Used as Internal User at Bristol							
5787	079089	Didcot Railway Centre					
Lot: 1510	Diagram: D.118	Built: 1934	Builder: Swindon	Bogied	Design: Collett	Seats: 32T	
Converted to BTU Tool Van in 1963							
5804	3406 ADW150304	Severn Valley Railway	Part of Ambulance Train 34 (1943-1946)				
CORRIDOR THIRD							TK
Lot: 1509	Diagram: C.67	Built: 1935	Builder: Swindon	Bogied	Design: Collett	Seats: 64T	
Converted to Emergency Control Train Coaches in 1957/62							
5813	TDW150324	Dean Forest Railway					
5856	TDW150031	West Somerset Railway					
5863	TDW150325	Dean Forest Railway					
BRAKE CORRIDOR THIRD							BTK
Lot: 1514	Diagram: D.118	Built: 1934	Builder: Swindon	Bogied	Design: Collett	Seats: 32T	
Used as Internal User at Briton Ferry							
5883	079135	Severn Valley Railway					
CORRIDOR THIRD							TK
Lot: 1527	Diagram: C.67	Built: 1935	Builder: Swindon	Bogied	Design: Collett	Seats: 64T	
5952	Didcot Railway Centre						
CORRIDOR COMPOSITE							CK
Lot: 1382	Diagram: E.132	Built: 1928	Builder: Swindon	Bogied	Design: Collett	Seats: 24F,24T	
Converted to BTU Staff & Dormitory Coach in 1962.							
6045	DW150293	Severn Valley Railway					
INSPECTION SALOON							SALOON
Lot: 1170	Diagram: Q.1	Built: 1910	Builder: Swindon	Bogied	Design: Churchward	Seats: 12U	
Built on underframe of Manchester & Milford Railway Composite 149, GWR 7900.							
6479	80977	Pontypool & Blaenavon Railway					
BRAKE CORRIDOR COMPOSITE							BCK
Lot: 1350	Diagram: E.128	Built: 1926	Builder: Swindon	Bogied	Design: Collett	Seats: 12F,32T	
Converted to S&T Staff & Tool Coach in 1961							
6515	KDW150270	South Devon Railway					
Lot: 1589	Diagram: E.159	Built: 1938	Builder: Swindon	Bogied	Design: Collett	Seats: 12F,32T	
6562	Severn Valley Railway						
6705	West Somerset Railway						
Lot: 1508	Diagram: E.148	Built: 1934	Builder: Swindon	Bogied	Design: Collett	Seats: 12F,32T	
Used as Internal User at Radyr							
6913	079134	Severn Valley Railway					
CORRIDOR COMPOSITE							CK
Lot: 1639	Diagram: E.162	Built: 1941	Builder: Swindon	Bogied	Design: Collett	Seats: 24F,24T	
7284 used as Internal User at Swindon Works							
7284	079156	Severn Valley Railway					
7285	Didcot Railway Centre						
Lot: 1621	Diagram: E.158	Built: 1940	Builder: Swindon	Bogied	Design: Collett	Seats: 24F,24T	
Used as Internal User at Swindon Works							
7313	079155	Didcot Railway Centre					
BRAKE CORRIDOR COMPOSITE							BCK
Lot: 1640	Diagram: E.159	Built: 1941	Builder: Swindon	Bogied	Design: Collett	Seats: 12F,32T	

7362	079151	used as Internal User at Swindon Works				
7371		Dean Forest Railway				
		Didcot Railway Centre				
Lot: 1690	Diagram: E.164	Built: 1948	Builder: Swindon	Bogied	Design: Hawksworth	Seats: 12F,32T
Royal Train Coaches						
7372		Didcot Railway Centre				
7377		South Devon Railway				
Lot: 1138	Diagram: E.83	Built: 1907	Builder: Swindon	Bogied	Design: Churchward	Seats: 12F,32T
Originally Brake Corridor Tri-Composites seating 12F,12S,16T. 7538 converted to a BTU Staff Coach in 1956. 7545 converted for S&T use in 1957, subsequently used as an Internal User at various locations on the BR Western Region.						
7538	DW150020	West Somerset Railway				
7545	KDW7545 079076	Swindon & Cricklade Railway				
CORRIDOR COMPOSITE						CK
Lot: 1171	Diagram: E.88	Built: 1911	Builder: Swindon	Bogied	Design: Churchward	Seats: 24F,24T
Converted to S&T Staff and Tool Van in 1955						
7740	KDW317	West Somerset Railway				
BRAKE CORRIDOR COMPOSITE						BCK
Lot: 1323	Diagram: E.114	Built: 1923	Builder: Swindon	Bogied	Design: Collett	Seats: 12F,32T
Used as Internal User at Exeter						
7976	079027	Didcot Railway Centre				
SPECIAL SALOON						SALOON
Lot: 1626	Diagram: G.62	Built: 1940	Builder: Swindon	Bogied	Design: Collett	Seats: 24F
6-wheel bogies						
9001		Buckinghamshire Railway Centre				
9002		Didcot Railway Centre				
FIRST CLASS SALOON						SALOON
Lot: 1431	Diagram: G.59	Built: 1930	Builder: Swindon	Bogied	Design: Collett	Seats: 20F
9004 converted to BR North Eastern Region Chief Civil Engineer's Saloon in 1963. 9005 used as BR Western Region General Manager's Saloon.						
9004	DE321011	Locomotive Services, Southall Depot				
9005		One:One Collection, Margate, Kent				
ROYAL SALOON						ROYAL
Lot: 1673	Diagram: G.64	Built: 1945	Builder: Swindon	Bogied	Design: Collett	Seats: 15
6-wheel bogies. Built on underframe of 1133, lot 1593, diagram C.77 of 1938. Contains two bedrooms, a bathroom, seating saloon, dining room, attendant's sleeping compartment and kitchen.						
9006		West Coast Railway Company, Carnforth				
Lot: 1673	Diagram: G.65	Built: 1945	Builder: Swindon	Bogied	Design: Collett	Seats: 7
6-wheel bogies. Built on underframe of 1598, lot 1574, diagram D.124 of 1937. Contains lounge, two large bedrooms and guards compartment.						
9007		West Coast Railway Company, Carnforth		National Collection		
FIRST CLASS SALOON						SALOON
Lot: 1209	Diagram: G.43	Built: 1912	Builder: Swindon	Bogied	Design: Churchward	Seats: 50F
Converted to Mobile Work Study Office in 1957						
9055	DW150127	Severn Valley Railway				
FIRST CLASS SLEEPING CAR						SLF
Lot: 1702	Diagram: J.18	Built: 1951	Builder: Swindon	Bogied	Design: Hawksworth	
6-wheel bogies, ten berths						
9082		Peak Railway, Rowsley, Derbyshire				
9083		Didcot Railway Centre				
9084		Severn Valley Railway				
9085		Severn Valley Railway				
THIRD CLASS SALOON						SALOON
Lot: 1400	Diagram: G.58	Built: 1929	Builder: Swindon	Bogied	Design: Collett	Seats: 44T
Used as Internal User at Danygraig						
9103	079124	Severn Valley Railway				
SUPER SALOON						SALOON
Lot: 1471	Diagram: G.60	Built: 1932	Builder: Swindon	Bogied	Design: Collett	Seats: 29F
9111		South Devon Railway		'KING GEORGE'		
9112		Didcot Railway Centre		'QUEEN MARY'		

Lot: 1471	Diagram: G.61	Built: 1932	Builder: Swindon	Bogied	Design: Collett	Seats: 29F
9118 Rebuilt with a Kitchen Diag. H.51						
9113		Didcot Railway Centre			'PRINCE OF WALES'	
9116		South Devon Railway			'DUCHESS OF YORK'	
9118		Didcot Railway Centre			'PRINCESS ELIZABETH'	
NONDESCRIPT SALOON						UO
Lot: 1250	Diagram: G.56	Built: 1923	Builder: Swindon	Bogied	Design: Churchward	Seats: 44U
Converted to Mobile Work Study Office in 1957						
9369	DW150128	Severn Valley Railway				
COMPOSITE RESTAURANT (with Kitchen)						RCK
Lot: 1349	Diagram: H.33	Built: 1925	Builder: Swindon	Bogied	Design: Collett	Seats: 12F,24T
Converted to Western Region S&T Managers Saloon in 1961						
9580	KDW150266	East Lancashire Railway				
FIRST CLASS RESTAURANT (with Kitchen)						RFK
Lot: 1468	Diagram: H.39	Built: 1932	Builder: Swindon	Bogied	Design: Collett	Seats: 23F
Converted to Mobile Work Study Office in 1962						
9615	DW150336	Severn Valley Railway				
THIRD CLASS RESTAURANT						RTO
Lot: 1469	Diagram: H.40	Built: 1932	Builder: Swindon	Bogied	Design: Collett	Seats: 63T
Used as Internal User at Roath Docks						
9627	079112	Severn Valley Railway				
UNCLASSIFIED RESTAURANT BUFFET (with						RUKB
Lot: 1518	Diagram: H.41	Built: 1934	Builder: Swindon	Bogied	Design: Collett	Seats: 12U
9631		Steam - Museum of The G.W.R., Swindon			National Collection	
FIRST CLASS RESTAURANT						RFO
Lot: 1540	Diagram: H.43	Built: 1935	Builder: Swindon	Bogied	Design: Collett	Seats: 24F
9635		Didcot Railway Centre				
THIRD CLASS RESTAURANT						RTO
Lot: 1359	Diagram: H.51	Built: 1925	Builder: Swindon	Bogied	Design: Collett	Seats: 63T
Built as articulated stock. 9653 is a rebuild of 10020, diagram H.32. 9654 is a rebuild of 10036, diagram H.32. Converted to Emergency Control Train Coaches in 1957/62.						
9653	TDW150032	Severn Valley Railway			National Collection	
9654	TDW150326	Severn Valley Railway				
INSPECTION SALOON						SALOON
Lot: 1701	Diagram: Q.13	Built: 1948	Builder: Swindon	Bogied	Design: Hawksworth	Seats: 23U
80943		Dean Forest Railway				
80969		Severn Valley Railway				
80970	DW80970	Great Central Railway				
80972		Severn Valley Railway				
80974		North Yorkshire Moors Railway				
80975	DW80975	Llangollen Railway				
80976	TDW80976	Pontypool & Blaenavon Railway			Loaned from West Somerset Railway	

NON-PASSENGER CARRYING COACHING STOCK

PASSENGER BRAKE, GANGWAYED

BG

Lot: 1667 64	Diagram: K.44	Built: 1941	Builder: Swindon	Bogied	Design: Collett
The Old Post House, Blakemere					
Lot: 1665 98	Diagram: K.42	Built: 1945	Builder: Swindon	Bogied	Design: Collett
Severn Valley Railway					
Lot: 1512 Used as Internal User at Reading 111	Diagram: K.41 060790	Built: 1934	Builder: Swindon	Bogied	Design: Collett
Didcot Railway Centre					
Lot: 1535 Converted for use as Seat Storage Vans in 1971 184	Diagram: K.41 ADB975157	Built: 1935	Builder: Swindon	Bogied	Design: Collett
Cholsey & Wallingford Railway					
185	ADB975158	Gloucestershire-Warwickshire Railway			

Lot: 1281 Used by British Steel at Llanwern Steel Works 261	Diagram: K.22	Built: 1922	Builder: Swindon	Bogied	Design: Churchward
Severn Valley Railway					
Lot: 1665 Converted to BTU Tool Van in 1977 276	Diagram: K.42 ADB975640	Built: 1945	Builder: Swindon	Bogied	Design: Collett
South Devon Railway					

Lot: 1722 Converted to Exhibition Train Generator Van in 1963 297	Diagram: K.45 ZDW150354	Built: 1949	Builder: Swindon	Bogied	Design: Hawksworth
Northampton & Lamport Railway					
Lot: 1740 316	Diagram: K.45	Built: 1950	Builder: Swindon	Bogied	Design: Hawksworth
Didcot Railway Centre					
Lot: 1752 334 converted to a Camping Coach after preservation. 333 334	Diagram: K.46	Built: 1951	Builder: Swindon	Bogied	Design: Hawksworth
Didcot Railway Centre				Camping Coach 172	
North Yorkshire Moors Railway					

POST OFFICE STOWAGE VAN

POT

Lot: 1666 Replacement Coach. Converted for use as an Enparts Van in 1971. 814	Diagram: L.23 ADB975156	Built: 1940	Builder: Swindon	Bogied	Design: Collett
Didcot Railway Centre					
Lot: 465 Built as Post Office Sorting Van (POS) with broad gauge bogies and numbered 599, bogies replaced with standard gauge bogies in 1891 and renumbered 2086. Converted to Post Office Stowage Van 1896, diagram L.12, modified to diagram L.3 in 1909. 841	Diagram: L.3	Built: 1889	Builder: Swindon	Bogied	Design: Dean
Railholiday, St.Germans Station, Cornwall					

PASSENGER BRAKE [non-gangwayed]

B

Lot: 883 Used as Internal User at Hockley Goods Depot, Birmingham 933	Diagram: K.14 064094	Built: 1903	Builder: Swindon	Bogied	Design: Dean
Didcot Railway Centre					

PASSENGER BRAKE, GANGWAYED

BG

Lot: 1301 1145 used as Internal User at Bristol. 1150 converted to CCE Drying Van in 1960. 1145 1150	Diagram: K.22 079038 DW150241	Built: 1922	Builder: Swindon	Bogied	Design: Churchward
Severn Valley Railway					
International Metals & Cable Recycling, Long Marston					
Lot: 1344 Converted to Medical Examination Coach in January 1945, Freight lot 1481, carriage diagram M.33. Renumbered into Departmental Stock in 1961. 1159	Diagram: K.36 DW150294	Built: 1925	Builder: Swindon	Bogied	Design: Churchward
Didcot Railway Centre					
Lot: 1413 1184	Diagram: K.40	Built: 1930	Builder: Swindon	Bogied	Design: Collett
Didcot Railway Centre					

AUTO-TRAILERS

AUTO-TRAILER

Lot: 1126 Diagram: N Built: 1907 Builder: Swindon
 Used as Internal User at Cardiff Canton Depot
38 079022 **Telford Steam Railway**

Lot: 1198 Diagram: U Built: 1912 Builder: Swindon
92 **Didcot Railway Centre**

Lot: 1394 Diagram: A.27 Built: 1929 Builder: Swindon
 163 converted to Work Study Coach in 1962. 167 & 169 used as Internal Users at Gloucester Depot
163 ADW150315 **South Devon Railway**
167 079050 **Chinnor & Princes' Risborough Railway**
169 064749 **West Somerset Railway**

Lot: 1410 Diagram: A.28 Built: 1930 Builder: Swindon
 174 converted to Staff Coach in 1962.
174 TDW150313 **Pontypool & Blaenavon Railway**
178 **Severn Valley Railway**

Lot: 1480 Diagram: A.30 Built: 1933 Builder: Swindon
 Used as Internal User at ?
190 079052 **Didcot Railway Centre**

Lot: 1736 Diagram: A.38 Built: 1951 Builder: Swindon
 233 converted to CM&EE Test Car 1 in 1966.
225 **South Devon Railway**
228 **South Devon Railway**
231 **Didcot Railway Centre**
232 **Bodmin Steam Railway**
233 ADW150375 **South Devon Railway**

Lot: 1766 Diagram: A.43 Built: 1954 Builder: Swindon
238 **Severn Valley Railway**
240 **South Devon Railway**

AUTO-TRAILER

Bogied Design: Churchward Seats: 64T

Bogied Design: Churchward Seats: 70T

Bogied Design: Collett Seats: 64T

Bogied Design: Collett Seats: 64T

Bogied Design: Collett Seats: 64T

Bogied Design: Hawksworth Seats: 64T

'Clare'

Bogied Design: Hawksworth Seats: 64T

'Charlotte'