

PASSENGER CARRYING COACHING STOCK [Dean]

FIRST CLASS SALOON

SALOON

Lot: 804 Diagram: G.31 Built: 1896 Builder: Swindon Bogied Design: Dean

Converted to Civil Engineer's Saloon in 1941.

231 8231 9035 80971 Pontypool & Blaenavon Railway

Lot: 840 Diagram: G.4 Built: 1897 Builder: Swindon Bogied Design: Dean
233 8233 9002 Steam - Museum of The G.W.R., Swindon Body only remains on u/f of BR MK 1 BSK 34626
234 8234 9003 Railholiday, St.Germans Station, Cornwall Body only remains on u/f of BR MK 1 BSK 34832 (745282)

FIRST CLASS SLEEPING CAR

SLF

Lot: 787 Diagram: J.5 Built: 1897 Builder: Swindon Bogied Design: Dean

Eight berths. Restored with underframe from GWR BCK 6912 - 079133.

242 8242 9038 West Somerset Railway

FIRST CLASS SALOON

SALOON

Lot: 241 Diagram: G.2 Built: 1881 Builder: Swindon Bogied Design: Dean

Numbered 248 until 1907. Converted to Civil Engineer's Saloon in 1936.

248 9044 80973 Bodmin Steam Railway 'MADAME PATIE'

DIRECTOR'S SALOON

SALOON

Lot: 745 Diagram: G.3 Built: 1894 Builder: Swindon Bogied Design: Dean Seats: 24F

Converted to Civil Engineer's Saloon in 1940.

249 8249 9045 80978 South Devon Railway

FIRST CLASS RESTAURANT (with Kitchen)

RFK

Lot: 801 Diagram: H.2 Built: 1896 Builder: Swindon Bogied Design: Dean Seats: 16F
250 8250 9501 Railholiday, St.Germans Station, Cornwall Body only remains on u/f of SR BTK 3204

LUGGAGE COMPOSITE [non-gangwayed]

LC

Lot: 206 Diagram: E.11 Built: 1882 Builder: Swindon Bogied Design: Dean Seats: ??F,??T
660 6660 Erwood Station Craft Centre & Museum, Powys Body only remains

DYNAMOMETER CAR

DYNAMOMETER

Lot: 293 Built: 1901 Builder: Swindon Bogied Design: Dean

Built under Wagon Lot 293

790 7 South Devon Railway

TRI-COMPOSITE (slip coach)

TRI-COMPOSITE

Lot: 890 Diagram: F.12 Built: 1898 Builder: Swindon Bogied Design: Dean
1091 7091 Railholiday, St.Germans Station, Cornwall Body only remains on replica u/f

THIRD [non-gangwayed]

T

Lot: 1038 Diagram: C.22 Built: 1903 Builder: Swindon Bogied Design: Dean

1357 DW14571 Didcot Railway Centre

COMPOSITE RESTAURANT (with Kitchen)

RCK

Lot: 1010 Diagram: H.7 Built: 1902 Builder: Swindon Bogied Design: Dean Seats: ??F,??T

Restored with underframe from GWR TK 3655.

1580 9520 Didcot Railway Centre

THIRD [non-gangwayed]

T

Lot: 962 Diagram: C.10 Built: 1901 Builder: Swindon Bogied Design: Dean
1941 DW14198 Didcot Railway Centre

PASSENGER CARRYING COACHING STOCK [Churchward, Collett, Hawksworth]

TK

CORRIDOR THIRD

Lot: 1623 Diagram: C.77 Built: 1940 Builder: Swindon Bogied Design: Collett Seats: 64T

Used as Internal User at Swindon Works

536 079152 **Didcot Railway Centre**

BTO

Lot: 1644 Diagram: D.130 Built: 1940 Builder: Swindon Bogied Design: Collett Seats: 40T

650 **Severn Valley Railway**

TK

CORRIDOR THIRD

Lot: 1691 Diagram: C.82 Built: 1948 Builder: Swindon Bogied Design: Hawksworth Seats: 64T

796 converted to a Dynamometer Car in 1961

796 ADW150192 **West Coast Railway Company, Carnforth**
829 **Severn Valley Railway**

Lot: 1593 Diagram: C.77 Built: 1938 Builder: Swindon Bogied Design: Collett Seats: 64T

Used as Internal Users at Swindon Works

1086 079154 **Severn Valley Railway**
1087 079158 **Severn Valley Railway**
1111 079159 **Didcot Railway Centre**
1116 079157 **Severn Valley Railway**
1146 079153 **Severn Valley Railway**

TO

OPEN THIRD

Lot: 1575 Diagram: C.74 Built: 1937 Builder: Swindon Bogied Design: Collett Seats: 64T

1285 **South Devon Railway**
1289 **Didcot Railway Centre**
1295 **South Devon Railway**

BTK

BRAKE CORRIDOR THIRD

Lot: 1594 Diagram: D.127 Built: 1938 Builder: Swindon Bogied Design: Collett Seats: 32T

Used as Internal User at Newton Abbot

1649 079170 **South Devon Railway**

TK

CORRIDOR THIRD

Lot: 1720 Diagram: C.82 Built: 1949 Builder: Swindon Bogied Design: Hawksworth Seats: 64T

2119 **Severn Valley Railway**

BTK

BRAKE CORRIDOR THIRD

Lot: 1732 Diagram: D.133 Built: 1950 Builder: Swindon Bogied Design: Hawksworth Seats: 32T

2180, 2216, 2225, 2232 & 2233 converted to CCE Staff & Dormitory Coaches in 1967/68

2180 DW150405 **South Devon Railway**
2202 **Didcot Railway Centre**
2216 DW150402 **Llangollen Railway**
2225 DW150392 **Cholsey & Wallingford Railway**
2232 DW150397 **Didcot Railway Centre**
2233 DW150401 **Severn Valley Railway**

32T

Lot: 1744 Diagram: D.133 Built: 1951 Builder: Swindon Bogied Design: Hawksworth Seats: 32T

Converted to CCE Staff & Dormitory Coach in 1967

2242 DW150391 **Severn Valley Railway**

Lot: 1174 Diagram: D.46 Built: 1911 Builder: Swindon Bogied Design: Churchward Seats: 32T

Converted to Track Recording Coach in 1930

2360 DW139 **Barry Tourist Railway** 'Whitewash Coach'

32T

Lot: 1180 Diagram: D.47 Built: 1911 Builder: Swindon Bogied Design: Churchward Seats: 32T

Converted to BTU Tool Van in 1955

2370 ADW309 **The Station Kitchen, West Bay, Dorset**

TK

CORRIDOR THIRD

Lot: 1167 Diagram: C.30 Built: 1910 Builder: Swindon Bogied Design: Churchward Seats: 64T

2426 converted to Camping Coach in 1952. 2434 converted to Staff & Dormitory Coach in 1956.

2426 9918 **Severn Valley Railway**
2434 DW150038 **South Devon Railway**

64T

Lot: 1172 Diagram: C.31 Built: 1911 Builder: Swindon Bogied Design: Churchward Seats: 64T

Converted to BTU Staff Coach in 1956

Lot: 1234 Diagram: C.32 Built: 1914 Builder: Swindon Bogied Design: Churchward Seats: 64T

Converted to Camping Coaches in 1957/58

2573 9879 **West Somerset Railway** 'CAROL'

2578 9889 **West Somerset Railway**

Lot: 1098 Diagram: C.24 Built: 1905 Builder: Swindon Bogied Design: Churchward Seats: 72T

Used as Internal User at Newquay

3299 079002 **Didcot Railway Centre**

Lot: 1286 Diagram: C.32 Built: 1921 Builder: Swindon Bogied Design: Churchward Seats: 64T

Rebuild of 3939, lot 1246 of 1915. Converted to Camping Coach in 1958.

3631 9880 **West Somerset Railway** 'FLORENCE'

Lot: 1289 Diagram: C.31 Built: 1921 Builder: Swindon Bogied Design: Churchward Seats: 64T

Rebuild of 24xx, lot 11xx of 1910. Converted to Camping Coach in 1957.

3639 9887 **West Somerset Railway**

Lot: 1295 Diagram: C.35 Built: 1921 Builder: Swindon Bogied Design: Churchward Seats: 64T

Rebuild of 3xxx, lot 12xx of 1917. Converted to Camping Coach in 1957.

3665 9886 **West Somerset Railway** 'BERYL'

Lot: 1313 Diagram: C.35 Built: 1922 Builder: Swindon Bogied Design: Churchward Seats: 64T

Rebuild of 3xxx, lot 12xx of 1917. Converted to Camping Coach in 1957.

3668 9888 **Gwendraeth Valley Railway, Coed Bach, nr Kidwelly**

BRAKE THIRD [non-gangwayed]

BT

Lot: 1275 Diagram: D.62 Built: 1921 Builder: Swindon Bogied Design: Churchward Seats: 60T

3755 **Didcot Railway Centre**

3756 **Didcot Railway Centre**

CORRIDOR THIRD

TK

Lot: 1269 Diagram: C.32 Built: 1920 Builder: Swindon Bogied Design: Churchward Seats: 64T

Converted to Camping Coaches in 1958

3885 3385 9882 **West Somerset Railway** 'HILDA'

3898 9884 **Swindon & Cricklade Railway** 'FREDA'

Lot: 1246 Diagram: C.32 Built: 1915 Builder: Swindon Bogied Design: Churchward Seats: 64T

3917 converted to a Camping Coach in 1958. 3930 converted to CCE Staff & Dormitory Coach in 1956.

3917 9883 **Llangollen Railway** Numbered 3719 'GRACE'

3930 DW150011 **Severn Valley Railway**

Lot: 1256 Diagram: C.35 Built: 1919 Builder: Swindon Bogied Design: Churchward Seats: 64T

Converted to Camping Coaches in 1957/58

3963 9885 **Didcot Railway Centre** 'ALICE'

3980 9881 **West Somerset Railway** 'ELSIE'

Lot: 1352 Diagram: C.54 Built: 1925 Builder: Swindon Bogied Design: Collett Seats: 64T

Converted to S&T Dormitory Coaches in 1959. KDW150205 subsequently used as Internal User at Westbourne Park.

4546 KDW150205 060903 **West Somerset Railway**

4553 KDW150207 **Didcot Railway Centre**

Lot: 1369 Diagram: C.54 Built: 1926 Builder: Swindon Bogied Design: Collett Seats: 64T

Converted to S&T Dormitory Coaches in 1959. KDW150206 subsequently used as Internal User at St.Austell Goods Yard and Exeter Red Cow Crossing.

4777 KDW150206 060907 **Honeybourne Airfield Industrial Estate**

4786 KDW150208 **Severn Valley Railway**

Lot: 1372 Diagram: C.54 Built: 1927 Builder: Swindon Bogied Design: Collett Seats: 64T

Converted to S & T Dormitory Coach in 1959.

4872 KDW150209 **South Devon Railway**

Lot: 1383 Diagram: C.54 Built: 1928 Builder: Swindon Bogied Design: Collett Seats: 64T

5043 converted to a BTU Staff Coach in 1963. 5085 converted to a S&T Dormitory Coach in 1959.

5043 ADW150301 **Severn Valley Railway**

5085 KDW150200 **Didcot Railway Centre**

BRAKE CORRIDOR THIRD

BTK

Lot: 1384 Diagram: D.95 Built: 1928 Builder: Swindon Bogied Design: Collett Seats: 32T

Converted to a CCE Staff & Tool Coaches in 1959.

5102 DW150234 **Llangollen Railway**

5131 DW150246 **West Somerset Railway**

BRAKE THIRD [non-gangwayed]

BT

Lot: 1493 Diagram: D.117 Built: 1934 Builder: Swindon Bogied Design: Collett Seats: 50T

Used as Internal User at Newport Docks

5500 071343 **Railway Support Services, Rye Farm, Wishaw**

Lot: 1392 Diagram: D.101 Built: 1928 Builder: Swindon Bogied Design: Collett Seats: 50T

Converted to BTU Staff Coach in 1962

5539 DW150328 **Railway Support Services, Rye Farm, Wishaw****BRAKE CORRIDOR THIRD**

BTK

Lot: 1490 Diagram: D.116 Built: 1933 Builder: Swindon Bogied Design: Collett Seats: 32T

Used as Internal User at Bristol

5787 079089 **Didcot Railway Centre**

Lot: 1510 Diagram: D.118 Built: 1934 Builder: Swindon Bogied Design: Collett Seats: 32T

Converted to BTU Tool Van in 1963

5804 3406 ADW150304 **Severn Valley Railway** Part of Ambulance Train 34 (1943-1946)**CORRIDOR THIRD**

TK

Lot: 1509 Diagram: C.67 Built: 1935 Builder: Swindon Bogied Design: Collett Seats: 64T

Converted to Emergency Control Train Coaches in 1957/62

5813 TDW150324 **Dean Forest Railway****5856** TDW150031 **West Somerset Railway****5863** TDW150325 **Dean Forest Railway****BRAKE CORRIDOR THIRD**

BTK

Lot: 1514 Diagram: D.118 Built: 1934 Builder: Swindon Bogied Design: Collett Seats: 32T

Used as Internal User at Briton Ferry

5883 079135 **Severn Valley Railway****CORRIDOR THIRD**

TK

Lot: 1527 Diagram: C.67 Built: 1935 Builder: Swindon Bogied Design: Collett Seats: 64T

5952 **Didcot Railway Centre****CORRIDOR COMPOSITE**

CK

Lot: 1382 Diagram: E.132 Built: 1928 Builder: Swindon Bogied Design: Collett Seats: 24F,24T

Converted to BTU Staff & Dormitory Coach in 1962.

6045 DW150293 **Severn Valley Railway****INSPECTION SALOON**

SALOON

Lot: 1170 Diagram: Q.1 Built: 1910 Builder: Swindon Bogied Design: Churchward Seats: 12U

Built on underframe of Manchester & Milford Railway Composite 149, GWR 7900.

6479 80977 **Pontypool & Blaenavon Railway****BRAKE CORRIDOR COMPOSITE**

BCK

Lot: 1350 Diagram: E.128 Built: 1926 Builder: Swindon Bogied Design: Collett Seats: 12F,32T

Converted to S&T Staff & Tool Coach in 1961

6515 KDW150270 **South Devon Railway**

Lot: 1589 Diagram: E.159 Built: 1938 Builder: Swindon Bogied Design: Collett Seats: 12F,32T

6562 **Severn Valley Railway****6705** **West Somerset Railway**

Lot: 1508 Diagram: E.148 Built: 1934 Builder: Swindon Bogied Design: Collett Seats: 12F,32T

Used as Internal User at Radyr

6913 079134 **Severn Valley Railway****CORRIDOR COMPOSITE**

CK

Lot: 1639 Diagram: E.162 Built: 1941 Builder: Swindon Bogied Design: Collett Seats: 24F,24T

7284 used as Internal User at Swindon Works

7284 079156 **Severn Valley Railway****7285** **Didcot Railway Centre**

Lot: 1621 Diagram: E.158 Built: 1940 Builder: Swindon Bogied Design: Collett Seats: 24F,24T

Used as Internal User at Swindon Works

7313 079155 **Didcot Railway Centre****BRAKE CORRIDOR COMPOSITE**

BCK

Lot: 1640 Diagram: E.159 Built: 1941 Builder: Swindon Bogied Design: Collett Seats: 12F,32T

7362 079151 **Dean Forest Railway**
 7371 **Didcot Railway Centre**

Lot: 1690 Diagram: E.164 Built: 1948 Builder: Swindon Bogied Design: Hawksworth Seats: 12F,32T

Royal Train Coaches

7372 **Didcot Railway Centre**
 7377 **South Devon Railway**

Lot: 1138 Diagram: E.83 Built: 1907 Builder: Swindon Bogied Design: Churchward Seats: 12F,32T

Originally Brake Corridor Tri-Composites seating 12F,12S,16T. 7538 converted to a BTU Staff Coach in 1956. 7545 converted for S&T use in 1957, subsequently used as an Internal User at various locations on the BR Western Region.

7538 DW150020 **West Somerset Railway**
 7545 KDW7545 079076 **Swindon & Cricklade Railway**

CORRIDOR COMPOSITE

CK

Lot: 1171 Diagram: E.88 Built: 1911 Builder: Swindon Bogied Design: Churchward Seats: 24F,24T

Converted to S&T Staff and Tool Van in 1955

7740 KDW317 **West Somerset Railway**

BRAKE CORRIDOR COMPOSITE

BCK

Lot: 1323 Diagram: E.114 Built: 1923 Builder: Swindon Bogied Design: Collett Seats: 12F,32T

Used as Internal User at Exeter

7976 079027 **Didcot Railway Centre**

SPECIAL SALOON

SALOON

Lot: 1626 Diagram: G.62 Built: 1940 Builder: Swindon Bogied Design: Collett Seats: 24F

6-wheel bogies

9001 **Buckinghamshire Railway Centre**
 9002 **Didcot Railway Centre**

FIRST CLASS SALOON

SALOON

Lot: 1431 Diagram: G.59 Built: 1930 Builder: Swindon Bogied Design: Collett Seats: 20F

9004 converted to BR North Eastern Region Chief Civil Engineer's Saloon in 1963. 9005 used as BR Western Region General Manager's Saloon.

9004 DE321011 **Locomotive Services, Southall Depot**
 9005 **One:One Collection, Margate, Kent**

ROYAL SALOON

ROYAL

Lot: 1673 Diagram: G.64 Built: 1945 Builder: Swindon Bogied Design: Collett Seats: 15

6-wheel bogies. Built on underframe of 1133, lot 1593, diagram C.77 of 1938. Contains two bedrooms, a bathroom, seating saloon, dining room, attendant's sleeping compartment and kitchen.

9006 **West Coast Railway Company, Carnforth**

Lot: 1673 Diagram: G.65 Built: 1945 Builder: Swindon Bogied Design: Collett Seats: 7

6-wheel bogies. Built on underframe of 1598, lot 1574, diagram D.124 of 1937. Contains lounge, two large bedrooms and guards compartment.

9007 **West Coast Railway Company, Carnforth** National Collection

FIRST CLASS SALOON

SALOON

Lot: 1209 Diagram: G.43 Built: 1912 Builder: Swindon Bogied Design: Churchward Seats: 50F

Converted to Mobile Work Study Office in 1957

9055 DW150127 **Severn Valley Railway**

FIRST CLASS SLEEPING CAR

SLF

Lot: 1702 Diagram: J.18 Built: 1951 Builder: Swindon Bogied Design: Hawksworth

6-wheel bogies, ten berths

9082 **Peak Railway, Rowsley, Derbyshire**
 9083 **Didcot Railway Centre**
 9084 **Severn Valley Railway**
 9085 **Severn Valley Railway**

THIRD CLASS SALOON

SALOON

Lot: 1400 Diagram: G.58 Built: 1929 Builder: Swindon Bogied Design: Collett Seats: 44T

Used as Internal User at Danygraig

9103 079124 **Severn Valley Railway**

SUPER SALOON

SALOON

Lot: 1471 Diagram: G.60 Built: 1932 Builder: Swindon Bogied Design: Collett Seats: 29F

9111 **South Devon Railway**
 9112 **Didcot Railway Centre**
 'KING GEORGE'
 'QUEEN MARY'

Lot: 1471	Diagram: G.61	Built: 1932	Builder: Swindon	Bogied	Design: Collett	Seats: 29F
9118 Rebuilt with a Kitchen Diag. H.51						
9113		Didcot Railway Centre			'PRINCE OF WALES'	
9116		South Devon Railway			'DUCHESS OF YORK'	
9118		Didcot Railway Centre			'PRINCESS ELIZABETH'	
NONDESCRIPT SALOON						
						UO
Lot: 1250	Diagram: G.56	Built: 1923	Builder: Swindon	Bogied	Design: Churchward	Seats: 44U
Converted to Mobile Work Study Office in 1957						
9369	DW150128	Severn Valley Railway				
COMPOSITE RESTAURANT (with Kitchen)						
						RCK
Lot: 1349	Diagram: H.33	Built: 1925	Builder: Swindon	Bogied	Design: Collett	Seats: 12F,24T
Converted to Western Region S&T Managers Saloon in 1961						
9580	KDW150266	East Lancashire Railway				
FIRST CLASS RESTAURANT (with Kitchen)						
						RFK
Lot: 1468	Diagram: H.39	Built: 1932	Builder: Swindon	Bogied	Design: Collett	Seats: 23F
Converted to Mobile Work Study Office in 1962						
9615	DW150336	Severn Valley Railway				
THIRD CLASS RESTAURANT						
						RTO
Lot: 1469	Diagram: H.40	Built: 1932	Builder: Swindon	Bogied	Design: Collett	Seats: 63T
Used as Internal User at Roath Docks						
9627	079112	Severn Valley Railway				
UNCLASSIFIED RESTAURANT BUFFET (with Kitchen)						
						RUKB
Lot: 1518	Diagram: H.41	Built: 1934	Builder: Swindon	Bogied	Design: Collett	Seats: 12U
9631		Steam - Museum of The G.W.R., Swindon			National Collection	
FIRST CLASS RESTAURANT						
						RFO
Lot: 1540	Diagram: H.43	Built: 1935	Builder: Swindon	Bogied	Design: Collett	Seats: 24F
9635		Didcot Railway Centre				
THIRD CLASS RESTAURANT						
						RTO
Lot: 1359	Diagram: H.51	Built: 1925	Builder: Swindon	Bogied	Design: Collett	Seats: 63T
Built as articulated stock. 9653 is a rebuild of 10020, diagram H.32. 9654 is a rebuild of 10036, diagram H.32. Converted to Emergency Control Train Coaches in 1957/62.						
9653	TDW150032	Severn Valley Railway			National Collection	
9654	TDW150326	Severn Valley Railway				
INSPECTION SALOON						
						SALOON
Lot: 1701	Diagram: Q.13	Built: 1948	Builder: Swindon	Bogied	Design: Hawksworth	Seats: 23U
80943		Dean Forest Railway				
80969		Severn Valley Railway				
80970	DW80970	Nottingham Heritage Centre, Ruddington				
80972		Severn Valley Railway				
80974		North Yorkshire Moors Railway				
80975	DW80975	Llangollen Railway				
80976	TDW80976	Pontypool & Blaenavon Railway			Loaned from West Somerset Railway	

NON-PASSENGER CARRYING COACHING STOCK

BG

PASSENGER BRAKE, GANGWAYED

Lot: 1667 Diagram: K.44 Built: 1941 Builder: Swindon Bogied Design: Collett

64 **The Old Post House, Blakemere**

Lot: 1665 Diagram: K.42 Built: 1945 Builder: Swindon Bogied Design: Collett

98 **Severn Valley Railway**

Lot: 1512 Diagram: K.41 Built: 1934 Builder: Swindon Bogied Design: Collett

Used as Internal User at Reading

111 **060790 Didcot Railway Centre**

Lot: 1535 Diagram: K.41 Built: 1935 Builder: Swindon Bogied Design: Collett

Converted for use as Seat Storage Vans in 1971

184 **ADB975157 Cholsey & Wallingford Railway**

185 **ADB975158 Gloucestershire-Warwickshire Railway**

Lot: 1281 Diagram: K.22 Built: 1922 Builder: Swindon Bogied Design: Churchward

Used by British Steel at Llanwern Steel Works

261 **Severn Valley Railway**

Lot: 1665 Diagram: K.42 Built: 1945 Builder: Swindon Bogied Design: Collett

Converted to BTU Tool Van in 1977

276 **ADB975640 South Devon Railway**

Lot: 1722 Diagram: K.45 Built: 1949 Builder: Swindon Bogied Design: Hawksworth

Converted to Exhibition Train Generator Van in 1963

297 **ZDW150354 Llangollen Railway**

Lot: 1740 Diagram: K.45 Built: 1950 Builder: Swindon Bogied Design: Hawksworth

316 **Didcot Railway Centre**

Lot: 1752 Diagram: K.46 Built: 1951 Builder: Swindon Bogied Design: Hawksworth

334 converted to a Camping Coach after preservation.

333 **Didcot Railway Centre**

334 **North Yorkshire Moors Railway** Camping Coach 172

POST OFFICE STOWAGE VAN

POT

Lot: 1666 Diagram: L.23 Built: 1940 Builder: Swindon Bogied Design: Collett

Replacement Coach. Converted for use as an Enparts Van in 1971.

814 **ADB975156 Didcot Railway Centre**

Lot: 465 Diagram: L.3 Built: 1889 Builder: Swindon Bogied Design: Dean

Built as Post Office Sorting Van (POS) with broad gauge bogies and numbered 599, bogies replaced with standard gauge bogies in 1891 and renumbered 2086. Converted to Post Office Stowage Van 1896, diagram L.12, modified to diagram L.3 in 1909.

841 **Railholiday, St.Germans Station, Cornwall**

PASSENGER BRAKE [non-gangwayed]

B

Lot: 883 Diagram: K.14 Built: 1903 Builder: Swindon Bogied Design: Dean

Used as Internal User at Hockley Goods Depot, Birmingham

933 **064094 Didcot Railway Centre**

PASSENGER BRAKE, GANGWAYED

BG

Lot: 1301 Diagram: K.22 Built: 1922 Builder: Swindon Bogied Design: Churchward

1145 used as Internal User at Bristol. 1150 converted to CCE Drying Van in 1960.

1145 **079038 Severn Valley Railway**

1150 **DW150241 Railway Support Services, Rye Farm, Wishaw**

Lot: 1344 Diagram: K.36 Built: 1925 Builder: Swindon Bogied Design: Churchward

Converted to Medical Examination Coach in January 1945, Freight lot 1481, carriage diagram M.33. Renumbered into Departmental Stock in 1961.

1159 **DW150294 Didcot Railway Centre**

Lot: 1413 Diagram: K.40 Built: 1930 Builder: Swindon Bogied Design: Collett

1184 **Didcot Railway Centre**

AUTO-TRAILERS

AUTO-TRAILER

Lot: 1126	Diagram: N	Built: 1907	Builder: Swindon	Bogied	Design: Churchward	Seats: 64T					
Used as Internal User at Cardiff Canton Depot											
38	079022	Telford Steam Railway									
Lot: 1198											
92	Diagram: U	Built: 1912	Builder: Swindon	Bogied	Design: Churchward	Seats: 70T					
Lot: 1394											
163	ADW150315	Cambrian Heritage Railway, Oswestry									
167	079050	Chinnor & Princes' Risborough Railway									
169	064749	West Somerset Railway									
163 converted to Work Study Coach in 1962. 167 & 169 used as Internal Users at Gloucester Depot											
Lot: 1410											
174	Diagram: A.28	Built: 1930	Builder: Swindon	Bogied	Design: Collett	Seats: 64T					
174 converted to Staff Coach in 1962.											
178	TDW150313	Pontypool & Blaenavon Railway									
190											
190 079052											
Didcot Railway Centre											
Used as Internal User at ?											
Lot: 1736											
225	Diagram: A.38	Built: 1951	Builder: Swindon	Bogied	Design: Hawksworth	Seats: 64T					
233 converted to CM&EE Test Car 1 in 1966, dual-braked.											
228	South Devon Railway										
231	South Devon Railway										
232	Didcot Railway Centre										
233	Bodmin Steam Railway					'Clare'					
233	ADW150375	South Devon Railway									
Lot: 1766											
238	Diagram: A.43	Built: 1954	Builder: Swindon	Bogied	Design: Hawksworth	Seats: 64T					
240	Severn Valley Railway					'Charlotte'					
S. A. Smith, Fox Road, Bourn, Cambridgeshire											

AUTO-TRAILER