

**DEPARTMENTAL VANS & WAGONS (new build)**

<b>TOOL VAN</b>					<b>DEPARTMENTAL</b>
Lot: 570	Built: 1908	Builder: Swindon	4-wheel		
Built under Wagon Lot 570 for Breakdown Train use.					
<b>1</b>	<b>Didcot Railway Centre</b>				
<b>4</b>	DW4	<b>Gloucestershire-Warwickshire Railway</b>			
<b>RIDING VAN</b>					<b>DEPARTMENTAL</b>
Lot: 695	Built: 1912	Builder: Swindon	4-wheel		
Built under Wagon Lot 695 for Breakdown Train use.					
<b>9</b>	DW9	<b>Severn Valley Railway</b>			
<b>BREAKDOWN CRANE MATCH &amp; COAL WAGON</b>					<b>DEPARTMENTAL</b>
Lot:	Built: 1945	Builder: Swindon	4-wheel		
Built to Wagon Lot xxxx for Breakdown Train use					
<b>19</b>	DW19 ADW150445	<b>Cambrian Heritage Railway, Oswestry</b>			
<b>RIDING VAN</b>					<b>DEPARTMENTAL</b>
Lot: 580	Built: 1908	Builder: Swindon	4-wheel		
Built under Wagon Lot 580 for Breakdown Train use.					
<b>47</b>	<b>Didcot Railway Centre</b>				
Lot: 571	Built: 1908	Builder: Swindon	4-wheel		
Built under Wagon Lot 571 for Breakdown Train use.					
<b>55</b>	DW55	<b>Severn Valley Railway</b>			
<b>56</b>	<b>Didcot Railway Centre</b>				
<b>TOOL VAN</b>					<b>DEPARTMENTAL</b>
Lot: 864	Built: 1921	Builder: Swindon	4-wheel		
Built under Wagon Lot 864 for Breakdown Train use.					
<b>66</b>	DW66	<b>Severn Valley Railway</b>			
<b>RIDING VAN</b>					<b>DEPARTMENTAL</b>
Lot: 580	Built: 1908	Builder: Swindon	4-wheel		
Built under Wagon Lot 580 for Breakdown Train use.					
<b>89</b>	DW89	<b>Severn Valley Railway</b>			
<b>TOOL VAN</b>					<b>DEPARTMENTAL</b>
Lot: 864	Built: 1921	Builder: Swindon	4-wheel		
Built under Wagon Lot for Breakdown Train use.					
<b>92</b>	DW92	<b>Gloucestershire-Warwickshire Railway</b>			
<b>WATER TANKER WAGON</b>					<b>DEPARTMENTAL</b>
Lot: 1555	Diagram: DD.6	Built: 1946	Builder: Swindon	6-wheel	
Built under Wagon Lot 1555 for Breakdown Train use.					
<b>101</b>	DW101 DW101W	<b>Didcot Railway Centre</b>			
<b>102</b>	DW102 ADW102	<b>West Somerset Railway</b>			
<b>106</b>	DW106 ADW106	<b>Gloucestershire-Warwickshire Railway</b>			
<b>TOOL VAN</b>					<b>DEPARTMENTAL</b>
Lot: 446	Built: 1904	Builder: Swindon	4-wheel		
Built under Wagon Lot 446 for Breakdown Train Use.					
<b>109</b>	DW109	<b>Didcot Railway Centre</b>		Body only, u/f used for 2511	
<b>112</b>	DW112	<b>Severn Valley Railway</b>			
Lot: 463	Built: 1904	Builder: Swindon	4-wheel		
Built under Wagon Lot 463 for Breakdown Train use.					
<b>118</b>	DW118	<b>Severn Valley Railway</b>			
Lot: 579	Built: 1908	Builder: Swindon	4-wheel		
Built under Wagon Lot 579 for Breakdown Train use					
<b>135</b>	<b>Didcot Railway Centre</b>				
<b>141</b>	DW141	<b>Severn Valley Railway</b>			
Lot: 718	Diagram: CC.8	Built: 1913	Builder: Swindon	4-wheel	
Built under Wagon Lot 718.					
<b>143</b>	DW143	<b>Severn Valley Railway</b>			

Lot: 579 Built: 1908 Builder: Swindon 4-wheel

Built under Wagon Lot 571 for Breakdown Train use.

**146** DW146 **South Devon Railway**

Lot: 903 Built: 1923 Builder: Swindon 4-wheel

Built under Wagon Lot 903 for Breakdown Train use.

**161** DW161 **Dean Forest Railway**

**RIDING VAN**

**DEPARTMENTAL**

Lot: 904 Built: 1923 Builder: Swindon 4-wheel

Built under Wagon Lot 904 for Breakdown Train use.

**162** DW162 **Severn Valley Railway**

**STAFF AND TOOL VAN**

**DEPARTMENTAL**

Lot: 1037 Built: 1930 Builder: Swindon Bogied

Built under Wagon Lot 1073 for Breakdown Train use.

**174** DW174 TDM174W **Battlefield Steam Railway**

**TOOL VAN**

**DEPARTMENTAL**

Lot: 767 Built: 1913 Builder: Swindon 4-wheel

Built under wagon lot 767 for S&T use.

**80982** **Severn Valley Railway**

**DEPARTMENTAL VANS & WAGONS (ex freight stock)****STAFF AND TOOL VAN****DEPARTMENTAL**

Lot: 549 Built: 1907 Builder: Swindon 4-wheel

Built under Wagon Lot 549 as Toad Brake Van 17711. Converted for S&amp;T use.

**262 DW262 Railway Support Services, Rye Farm, Wishaw**

Lot: 477 Built: 1905 Builder: Swindon 4-wheel

Built under Wagon Lot 477 as Toad Brake Van 56867. Converted for S&amp;T use.

**263 DW263 Didcot Railway Centre****STORES VAN****DEPARTMENTAL**

Lot: Built: 1914 Builder: ? 4-wheel

Built as Iron Mink for Barry Railway numbered 1388, becoming GWR 48901. Conveerted for Traffic Department use. Used as Internal User at Shrewsbury Station.

**298 DW298 024303 Gloucestershire-Warwickshire Railway****STAFF VAN****DEPARTMENTAL**

Lot: Built: 1898 Builder: Swindon 4-wheel

Built under Wagon Lot xxxx as Toad Brake Van 56322. Converted for CCE use. Used as Internal User at Honeybourne Tip.

**300 DW300 070837 Honeybourne Airfield Industrial Estate****TOOL VAN****DEPARTMENTAL**

Lot: Built: 1910 Builder: Swindon 4-wheel

Built on Wagon Lot xxx as Mink 26919. Converted for S&amp;T use.

**80964 KDW80964 Helston Railway, Prospidnick, Cornwall****PACKING VAN****DEPARTMENTAL**

Lot: Built: 1923 Builder: Swindon 4-wheel

Built under Wagon Lot xxx as Mink A 101961 . Converted for Breakdown Train use.

**150066 DW150066 Severn Valley Railway****TEST WEIGHTS WAGON****DEPARTMENTAL**

Lot: Built: 1899 Builder: Swindon 4-wheel

Built on Wagon Lot xxx as Ballast Wagon 80005. Converted for use by Pooley Weighing Machine Contractor's.

**150260 DW150260 Gloucestershire-Warwickshire Railway**

Lot: Built: 1900 Builder: Swindon 4-wheel

Built on Wagon Lot xxx as Ballast Wagon 60562. Converted for use by Pooley Weighing Machine Contractor's.

**150262 DW150262 Severn Valley Railway**