

COACHING STOCK BUILT TO WAGON LOT NUMBERS

FERRY MOTOR CAR VAN

Lot no: 2848	Builder: Lancing	Built: 1958	Diagram: 1/291	Design code: ZQ093	Bogies: 4-whl
889000		Swanage Railway			UIC No. 2170-219-9-000-7
889006		Great Central Railway			UIC No. 2170-219-9-006-4
889007		Flour Mill Workshop, Bream			UIC No. 2170-219-9-007-2
889009		South Devon Railway			UIC No. 2170-219-9-009-8
889011		East Lancashire Railway			UIC No. 2170-219-9-011-4
889014		Dean Forest Railway			UIC No. 2170-219-9-014-8
889015		South Devon Railway			UIC No. 2170-219-9-015-5
889016		Gloucestershire-Warwickshire Railway			UIC No. 2170-219-9-016-3
889017		East Somerset Railway			UIC No. 2170-219-9-017-1
889018		Hardingham Station, Norfolk			UIC No. 2170-219-9-018-9
889019		The Old Post House, Blakemere			UIC No. 2170-219-9-019-7
Lot no: 3022	Builder: Lancing	Built: 1958	Diagram: 1/291	Design code: ZQ093	Bogies: 4-whl
889020 used as Internal User at Morpeth					
889020	042187	Eden Valley Railway			UIC No. 2170-219-9-020-5
889022		Dartmoor Railway, Okehampton			UIC No. 2170-219-9-022-1
889027		Exeter & Teign Valley Railway			UIC No. 2170-219-9-027-0

FERRY SCENERY VAN

Lot no: 2849	Builder: Eastleigh	Built: 1958	Diagram: 1/292	Design code: YR025	Bogies: BR2
889202 rebogied with CW's					
889200		British Pullman, Stewarts Lane Depot			UIC No. 2170-239-7-000-7
889202		British Pullman, Stewarts Lane Depot			UIC No. 2170-239-7-002-3

BOGIE FLATROL WAGON

Lot no: 2005	Builder: Derby	Built: 1950	Diagram: 2/511	Design code: YV010	
900402		Locomotion: The NRM at Shildon			NRM95400

MOTORAIL LOADING WAGON

Lot no: 3102	Builder: Swindon	Built: 1960	Design code: NG503		
Converted from Weltrol wagons					
900912	96451	Midland Railway-Butterley			
900920	96450	Bluebell Railway			

INSPECTION SALOON

Lot no: 3093	Builder: Wolverton	Built: 1957	Diagram: 550	Bogies: BR2	Seats: 13
999501		Peak Railway, Darley Dale			
999502		Bo'ness & Kinneil Railway			
999503		Great Central Railway			
999504		Ecclesbourne Valley Railway, Wirksworth			
Lot no: 3379	Builder: Swindon	Built: 1960	Diagram: 552	Bogies: BR2	
999508		West Somerset Railway			
999509		L&NWR Heritage Company, Crewe			

CAR FLAT

Lot no: ????	Builder:	Built:			
B94123		Swindon & Cricklade Railway			MAT CARFLAT