

**PASSENGER BRAKE [non-gangwayed]****B**

Diagram: 310 Built: 1921 Builder: Doncaster Design: Gresley

Pre-grouping GNR carriage. Converted to Crane Runner in 1961 (bodywork removed).

2391 49 **49** DE320883 Embsay & Bolton Abbey Railway u/f only remains used for NER 3170**PASSENGER BRAKE, GANGWAYED****BG**

Diagram: EC33C Built: 1908 Builder: Doncaster Design: Gresley

Pre-grouping ECJS carriage. Used as part of the LNER Royal Train. Used as Internal User at Bounds Green and later at Wolverton Works.

82 109 **109** 040880 Locomotion: The NRM at Shildon  
Order No: 1180 Diagram: 344 Built: 1948 Builder: York Design: Thompson  
**110** North Yorkshire Moors Railway**H.M. THE KING'S SALOON****ROYAL**

Diagram: EC81 Built: 1908 Builder: Doncaster Design: Gresley

Pre-grouping ECJS carriage. 6-whl bogies.

395 **395** National Railway Museum, York National Collection**H.M. THE QUEEN'S SALOON****ROYAL**

Diagram: EC82 Built: 1908 Builder: York Design: Gresley

Pre-grouping ECJS carriage. 6-whl bogies.

396 **396** Bressingham Live Steam Museum**PASSENGER BRAKE [non-gangwayed]****B**

Diagram: GN293 Built: 1910 Builder: Doncaster Design: Gresley

Pre-grouping GNR carriage. Converted to ? in 195x, later converted to Crane Runner in 1961 (bodywork removed)

3168 449 **449** DE320410 DE320878 Colne Valley Railway Reduced to Crane Runner**THIRD CLASS RESTAURANT****RTO**

Diagram: EC25 Built: 1894 Builder: Doncaster Design: Stirling Seats: 33T

Pre-grouping ECJS carriage.

189 1189 **1189** North Yorkshire Moors Railway Body only remains on u/f LNER 16175**FIRST CLASS SLEEPING CAR****SLF**

Order No: 601 Diagram: 157 Built: 1935 Builder: Doncaster Design: Gresley Seats: 10 berths

1211 **1211** Bo'ness & Kinneil Railway SR No.178.

Diagram: EC66 Built: 1896 Builder: York Design: NER Seats: 10 Berths

Pre-grouping ECJS carriage.

236 1236 **1236** Newton-on-Ouse, near York Body only remains on u/f GER 2163**THIRD CLASS SLEEPING CAR (convertible)****SLT(C)**

Order No: 356 Diagram: 109 Built: 1930 Builder: York Design: Gresley Seats: 56T or 28 berths

Converted to CCE Staff Coach in 1961

1299 **1299** DE320931 North Yorkshire Moors Railway**CORRIDOR THIRD****TK**

Order No: 1282 Diagram: 329 Built: 1950 Builder: York Design: Thompson Seats: 42T

Converted to CCE Staff Coach in 1968

**1623** DE321133 North Yorkshire Moors Railway**RESTAURANT LOUNGE BUFFET (with Kitchen)****RLKB**

Order No: 1197 Diagram: 352 Built: 1948 Builder: Doncaster Design: Thompson Seats: 8

Converted to Restaurant Unclassified Buffet (with Kitchen) by British Rail in 1959. Seats: 24. Subsequently converted to CCE Staff Coach in 1979.

**1706** DB975882 Llangollen Railway**CORONATION OBSERVATION SALOON****SALOON**

Order No: 809 Diagram: 232 Built: 1937 Builder: Doncaster Design: Gresley Seats: 16

1719 **1719** Great Central Railway  
1729 **1729** Nemesis Rail, Burton-upon-Trent**RESTAURANT LOUNGE BUFFET (with Kitchen)****RLKB**

Order No: 842 Diagram: 258 Built: 1938 Builder: Doncaster Design: Gresley Seats: 20F

Converted to Restaurant Unclassified Buffet (with Kitchen) by British Rail.

1852 **1852** Stainmore Railway, Kirkby Stephen East**BRAKE CORRIDOR THIRD****BTK**

Order No: 1288 Diagram: 346 Built: 1950 Builder: Doncaster Design: Thompson Seats: 24T

Converted to CCE Staff &amp; Tool Coach in 1967

1866 DE321120

North Norfolk Railway

**OPEN THIRD****TO**

Diagram: NE155 Built: 1924 Builder: York

Design: Gresley Seats: 42T

North Eastern Railway order. Converted to Mobile Work Study Office Coach in 1959.

945 2945 **2945** DE320716

North Yorkshire Moors Railway

Stored at RSR Northeast, Spennymoor

**BRAKE CORRIDOR COMPOSITE****BCK**

Diagram: 218F Built: 1912 Builder: Doncaster

Design: Gresley Seats: 12F, 24T

Pre-grouping GNR carriage. Converted to ? in 1959.

229 4229 **4229** TDE320700

Mangapps Farm Railway Museum

**FIRST CLASS SALOON****SALOON**

Diagram: 45D Built: 1912 Builder: Doncaster

Design: Gresley Seats: 14F

Pre-grouping GNR carriage. Converted to ? in 195x.

397 4397 **4397** DE320206

The Carriage Inn, Jesmond

**FIRST CLASS RESTAURANT (with Kitchen)****RFK**

Order No: 260 Diagram: 10C Built: 1929 Builder: Doncaster

Design: Gresley Seats: 18F

9007 converted to BTU Tool Van in 1963, 9019 converted to CCE Staff &amp; Dormitory Coach in 1961.

42969 **9007** ADE320947

North Yorkshire Moors Railway

1222 651 **9019** DE320907

Great Central Railway

**THIRD CLASS RESTAURANT (with Kitchen)****RTK**

Order No: 198 Diagram: 112 Built: 1928 Builder: York

Design: Gresley Seats: 39T

Converted to Office Coach in 196x.

42972 **9066** TDE320927

Mangapps Farm Railway Museum

**UNCLASSIFIED RESTAURANT BUFFET (with Kitchen)****RUKB**

Order No: 702 Diagram: 167 Built: 1936 Builder: York

Design: Gresley Seats: 24

9116 converted to Staff Coach in 1965, later used as Internal User at Perth Carriage Sidings.

24079 **9115** Rowler Manor, Croughton, Northamptonshire24080 **9116** TDE321069 096055 Great Central Railway24082 **9118** Epping Ongar Railway

Order No: 761 Diagram: 167 Built: 1937 Builder: York Design: Gresley Seats: 24

24278 **9122** Great Central Railway24279 **9123** Rushden Station Museum, Northamptonshire24280 **9124** Great Central Railway51769 **9128** North Norfolk Railway641 **9129** North Yorkshire Moors Railway643 **9131** Severn Valley Railway644 **9132** Bo'ness & Kinneil Railway649 **9134** Nemesis Rail, Burton-upon-Trent650 **9135** National Railway Museum, York National Collection**COMPOSITE RESTAURANT (with Kitchen)****RCK**

Order No: 673 Diagram: 187 Built: 1936 Builder: Doncaster

Design: Gresley Seats: 12F, 18T

Converted to CCE Staff Coach in 1964

7960 **9162** DE321021 Severn Valley Railway**UNCLASSIFIED RESTAURANT BUFFET (with Kitchen)****RUKB**

Order No: 784 Diagram: 275 Built: 1939 Builder: Dukinfield

Design: Gresley Seats: 30

24287 **9195** Stainmore Railway, Kirkby Stephen East**BRAKE CORRIDOR COMPOSITE****BCK**

Order No: 48 Diagram: 34 Built: 1924 Builder: York

Design: Gresley Seats: 12F, 12T

Converted to BTU Staff &amp; Tool Coach in 1958, later used as Internal User at Blyth Cambois Depot.

10178 1077 52181 **10021** ADE320427 041469 North Yorkshire Moors Railway

Order No: 700 Diagram: 175 Built: 1937 Builder: York

Design: Gresley Seats: 12F, 24T

24068 **10078** Severn Valley Railway**BRAKE CORRIDOR FIRST****BFK**

Order No: 191 Diagram: 136 Built: 1928 Builder: York

Design: Gresley Seats: 18F

Converted to BTU Staff &amp; Dormitory Coach in 1960

4163 **11047** ADE320797 Stainmore Railway, Kirkby Stephen East**CORRIDOR THIRD****TK**

Order No: 47 Diagram: 23 Built: 1924 Builder: York

Design: Gresley Seats: 48T

Converted to ? in ?

10021 1002 4464 **12041** DE320874 Bo'ness & Kinneil Railway

**THIRD CLASS RESTAURANT****RTO**

Order No: 382 Diagram: 27A Built: 1931 Builder: Doncaster Design: Gresley Seats: 48T

Converted to ? in ?

6118 12190 DE320897 Llangollen Railway underframe only remains

**CORRIDOR THIRD****TK**

Diagram: 115 Built: 1935 Builder: Birmingham R.C.W.Co. Design: Gresley Seats: 64T

Converted to Emergency Control Train Coaches in 1962

23890 12322 TDE320959 North Yorkshire Moors Railway

23896 12328 TDE321008 North Yorkshire Moors Railway Stored at RSR Northeast, Spennymoor

Diagram: 115 Built: 1931 Builder: Metropolitan-Cammell Design: Gresley Seats: 64T

12466 converted to CCE Staff &amp; Dormitory Coach in 1961, 12481 converted to Emergency Control Train Coach in 1962, 12493 converted to ? in ?

3132 12466 DE320894 Bere Ferrers Station Museum, Devon

3291 12481 TDE321007 North Yorkshire Moors Railway

3395 12493 DE320877 North Norfolk Railway

Order No: 508 Diagram: 115 Built: 1934 Builder: York Design: Gresley Seats: 64T

Converted to CCE Staff &amp; Dormitory Coach in 1963

1459 12735 DE320966 Bere Ferrers Station Museum, Devon

Order No: 488 Diagram: 155 Built: 1934 Builder: York Design: Gresley Seats: 42T

3188 12934 Weardale Railway

Order No: 620 Diagram: 155 Built: 1936 Builder: York Design: Gresley Seats: 42T

Converted to CCE Staff &amp; Dormitory Coach 1962

3857 12961 DE320946 Stainmore Railway, Kirkby Stephen East

**OPEN THIRD****TO**

Diagram: 186 Built: 1936 Builder: Birmingham R.C.W.Co. Design: Gresley Seats: 64T

13279 converted to Staff Coach in 1965, later used as Internal User at Perth Carriage Sidings

23953 13251 East Anglian Railway Museum

23956 13254 North Yorkshire Moors Railway National Collection

23981 13279 TDE321070 096056 Great Central Railway

Diagram: 186 Built: 1936 Builder: Metropolitan Cammell Design: Gresley Seats: 64T

Converted to Emergency Control Train Coaches in 1962

24105 13317 TDE320957 Severn Valley Railway

24109 13320 TDE320956 North Yorkshire Moors Railway Stored at RSR Northeast, Spennymoor

Order No: 559 Diagram: 186 Built: 1934-35 Builder: York Design: Gresley Seats: 64T

13354/85, 13407 converted to Emergency Control Train Coaches in 1962, 13366 used as Internal User at Norwich Goods Yard.

43600 13354 TDE320960 Severn Valley Railway

43612 13366 042197 Severn Valley Railway

43632 13385 TDE321006 North Yorkshire Moors Railway

43654 13407 TDE321001 North Yorkshire Moors Railway

Order No: 594 Diagram: 186 Built: 1935 Builder: York Design: Gresley Seats: 64T

Converted to Emergency Control Train Coaches in 1962

52255 13547 TDE321005 Severn Valley Railway

52256 13548 TDE321002 North Norfolk Railway

Diagram: 186 Built: 1938 Builder: Metropolitan Cammell Design: Gresley Seats: 64T

Converted to Medical Coach in 1966

56856 13577 TDE321108 North Yorkshire Moors Railway

Order No: 1126 Diagram: 330 Built: 1947 Builder: York Design: Thompson Seats: 64T

13803 Bo'ness &amp; Kinneil Railway

**BRAKE CORRIDOR THIRD****BTK**

Order No: 837 Diagram: 37A Built: 1938 Builder: Doncaster Design: Gresley Seats: 30T

Converted to ? in 1965.

41384 16076 DE321058 Buckinghamshire Railway Centre

Order No: 59 Diagram: 38 Built: 1924 Builder: Stratford Design: Gresley Seats: 24T

Converted to BTU Staff &amp; Tool Coach in 1958

62515 930 16122 ADE320680 Bo'ness &amp; Kinneil Railway

Order No: 70 Diagram: 40 Built: 1925 Builder: Doncaster Design: Gresley Seats: 24T

Converted to BTU Tool Van in 1959, later used as Internal User at Perth Carriage Sidings.

62540 16175 ADE320692 096060 North Yorkshire Moors Railway underframe only remains, used for ECJS 189

Diagram: 114 Built: 1930 Builder: Birmingham R.C.W.Co. Design: Gresley Seats: 32T

Converted to BTU Staff Coach in 1962

3669 16335 ADE320984 Stainmore Railway, Kirkby Stephen East

Order No: 953 Diagram: 178 Built: 1940 Builder: York Design: Gresley Seats: 36T

57451 16520 Great Central Railway

**BRAKE OPEN THIRD****BTO**

Order No: 565 Diagram: 191 Built: 1935 Builder: York Design: Gresley Seats: 32T

16551 converted to CCE Weedkilling Train Spray Coach in 1963

43567 **16547** North Yorkshire Moors Railway

43571 **16551** DE320995 88001 Colne Valley Railway

Diagram: 196 Built: 1938 Builder: Cravens Design: Gresley Seats: 48T

43556 **16631** Epping Ongar Railway

### BRAKE CORRIDOR COMPOSITE

**BCK**

Order No: 66 Diagram: 34 Built: 1926 Builder: York Design: Gresley Seats: 12F, 12T

Converted to BTK in 1942, Diagram 324, Seats 24T. Converted to CCE Staff & Dormitory Coach in 1958.

1083 24680 **16847** DE320645 British Pullman, Stewarts Lane Depot underframe only remains

### CORRIDOR COMPOSITE

**CK**

Order No: 45 Diagram: 7 Built: 1924 Builder: York Design: Gresley Seats: 15F, 30T

Converted to Staff & Tool Van in 195x.

10155 1065 7781 **18033** DE320741 Great Central Railway

Order No: 1280 Diagram: 328 Built: 1950 Builder: York Design: Thompson Seats: 18F, 18T

**18477** North Yorkshire Moors Railway

### BRAKE CORRIDOR THIRD

**BTK**

Diagram: 258 Built: 1906 Builder: Doncaster Design: Gresley Seats: 30T

Pre-grouping GNR carriage. Converted to BTU ? Van in 195x.

1798 41798 **41798** DE320145 Stainmore Railway, Kirkby Stephen East

### CORRIDOR THIRD

**TK**

Diagram: EC14 Built: 1898 Builder: York Design: NER Seats: 36T

Pre-grouping ECJS carriage.

12 112 41805 **41805** National Railway Museum, York National Collection

Diagram: 220 Built: 1906 Builder: Doncaster Design: Gresley Seats: 42T

Pre-grouping GNR carriage. Converted to BTU Tool Van in 1954, later used as Internal User at Cambridge depot.

2440 42440 **42440** ADE320154 041975 Colne Valley Railway

### CORRIDOR COMPOSITE

**CK**

Diagram: 164K Built: 1922 Builder: Doncaster Design: Gresley Seats: 21F, 32T

Pre-grouping GNR carriage. Converted to Camping Coach in 1958. Converted to CCE Staff & Workshop coach in 196x, later used as Internal User at Boston station.

2701 42701 **42701** CC157 DE321089 041593 Severn Valley Railway

### INVALID SALOON

**SALOON**

Diagram: 10 Built: 1909 Builder: Doncaster Design: Gresley

Pre-grouping GNR carriage. Converted to ? in ?

3087 43087 **43087** DE320042 North Yorkshire Moors Railway

### BRAKE CORRIDOR FIRST

**BFK**

Diagram: 97 Built: 1910 Builder: Doncaster Design: Gresley Seats: 20F

Pre-grouping GNR carriage. Converted to BTU Tool Van in 195x.

3178 43178 **43178** DE320651 Mangapps Farm Railway Museum

### CORRIDOR THIRD

**TK**

Diagram: EC22 Built: 1907 Builder: Doncaster Design: Gresley Seats: 48T

Pre-grouping ECJS carriage. Converted to CCE Staff & Dormitory Coach in 1957.

377 1377 52055 **52055** DE320444 Llangollen Railway

### OPEN THIRD

**TO**

Order No: 639 Diagram: 216 Built: 1936 Builder: York Design: Gresley Seats: 52T

Converted to CCE Staff & Dormitory Coach in 1964

60505 **60505** DE321048 Stainmore Railway, Kirkby Stephen East

Order No: 661 Diagram: 216 Built: 1936 Builder: York Design: Gresley Seats: 52T

Converted to CCE Staff & Dormitory Coach in 1964

60525 **60525** DE321049 North Yorkshire Moors Railway u/f only remains Stored at DC Engineering & Restorations, Shildon

### CORRIDOR THIRD

**TK**

Order No: 107 Diagram: 25 Built: 1926 Builder: Stratford Design: Gresley Seats: 56T

Converted to ? in ?

61634 **61634** DE320904 Nene Valley International Steam Railway

### BRAKE CORRIDOR THIRD

**BTK**

Order No: 146 Diagram: 41 Built: 1927 Builder: York Design: Gresley Seats: 24T

Converted to ? in ?

62565 **62565** DE320746 Great Central Railway

**PARCELS & MISCELLANEOUS VAN****PMV**

Order No: 125 Diagram: 86 Built: 1926-27 Builder: Stratford

Converted to Crane Runners in 1962/64 (bodywork removed).

6259	<b>70107</b>	DE320952	National Railway Museum, York	Reduced to Crane Runner	National Collection
6282	<b>70130</b>	DE321051	Stephenson Railway Museum	Reduced to Crane Runner	

Order No: 325 Diagram: 120 Built: 1929-30 Builder: York

70246 used as Internal User at ?

6843	772	<b>70246</b>	040923	North Norfolk Railway	
6854	776	<b>70250</b>		Llangollen Railway	

**PASSENGER BRAKE, GANGWAYED****BG**

Order No: 400 Diagram: 129 Built: 1931 Builder: Doncaster Design: Gresley

6777 **70268** Great Central Railway**POST OFFICE SORTING VAN****POS**

Order No: 787 Diagram: 164 Built: 1937 Builder: York Design: Gresley

2441 **70294** Great Central Railway**PASSENGER BRAKE, GANGWAYED****BG**

Order No: 656 Diagram: 198 Built: 1936 Builder: York Design: Gresley

4149 US2704 **70361** Great Central Railway Formed in WWII Ambulance Train 27

Order No: 1017 Diagram: 245 Built: 1941 Builder: York Design: Gresley

4050 **70427** Great Central Railway

Order No: 777 Diagram: 245 Built: 1938 Builder: York Design: Gresley

70460 converted to BTU Tool Van in 1972

4237	<b>70460</b>	ADB975242	Poulton & Wyre Railway		
4247	<b>70470</b>		Keighley & Worth Valley Railway	K&WVR No.106	

Order No: 983 Diagram: 245 Built: 1940 Builder: York Design: Gresley

70491 converted to Exhibition Van

4268	<b>70491</b>	MM3023 99628 ZDB975399	Doldowlod Caravan Park, near Rhayder		
4271	<b>70494</b>		Bo'ness & Kinneil Railway		

Order No: 1123 Diagram: 327 Built: 1945-46 Builder: York Design: Thompson

70630 converted to Exhibition Van

	<b>70621</b>		North Norfolk Railway		
	<b>70630</b>	MM3022 99627 ZDB975401	West Coast Railway Company, Carnforth		

**PASSENGER BRAKE [non-gangwayed] (six-wheel)****BZ**

Order No: 1284 Diagram: 358 Built: 1950 Builder: Stratford Design: Thompson

	<b>70654</b>		Great Central Railway		
	<b>70687</b>		Embsay & Bolton Abbey Railway	u/f only remains	
	<b>70692</b>		Mangapps Farm Railway Museum	u/f only remains used for GER 76	
	<b>70xxx</b>		National Museum of Wales, Nantgarw	u/f only remains	

**PASSENGER BRAKE, GANGWAYED****BG**

Order No: 1073 Diagram: 245 Built: 1943 Builder: York Design: Gresley

70754 used as Internal User at Heaton depot. 70759 restored as BTK using enderframe from LNER BG 70442.

	<b>70754</b>	041366	RSR Northeast, Spennymoor, County Durham		
	<b>70759</b>		Severn Valley Railway		

**FISH VAN****FISH**

Diagram: 214 Built: 1949-50 Builder: Faverdale

75169 used as Internal User at Doncaster Works

	<b>75169</b>	041255	North Yorkshire Moors Railway		
	<b>75302</b>		Ribble Steam Railway, Preston	u/f only remains used for NLR Birdcage Passenger Brake ?	

**BRAKE COMPOSITE****BC**

Diagram: 360 Built: 1952 Builder: Birmingham R.C.W.Co. Design: Thompson Seats: 16F, 40T

**80417** Bo'ness & Kinneil Railway**FIRST [non-gangwayed]****F**

Order No: 148 Diagram: 48 Built: 1927 Builder: York Design: Gresley Seats: 56F

Converted to CCE Staff &amp; Tool Coach in 1960, later used as Internal User at Immingham Dock.

6450	<b>81052</b>	ADE320889 041568	North Yorkshire Moors Railway	u/f only remains. stored at DC Engineering & Restorations, Shildon	
------	--------------	------------------	-------------------------------	--	--

**THIRD [non-gangwayed]****T**

Diagram: 56 Built: 1926 Builder: Metropolitan Cammell Design: Gresley Seats: 80T

Converted to ? in ?

22299 774 **82145** DE320832 Buckinghamshire Railway Centre May be 22943, 775, 82146?  
 Diagram: 57 Built: 1927 Builder: Cravens Design: Gresley Seats: 80T

Converted to CCE Staff & Dormitory Coach in 1960.

61684 **82347** DE320803 Mangapps Farm Railway Museum

### **BRAKE THIRD [non-gangwayed]**

**BT**

Diagram: 64 Built: 1926 Builder: Clayton Design: Gresley Seats: 40T

Converted to S&T ? in ?

3641 **86056** KDE320779 Mangapps Farm Railway Museum  
 Order No: 207 Diagram: 65 Built: 1927 Builder: York Design: Gresley Seats: 40T

Converted to Crane Runner in 1961 (bodywork removed).

22313 **86062** DE320882 Chasewater Light Railway Reduced to Crane Runner  
 Order No: 149 Diagram: 65 Built: 1926 Builder: York Design: Gresley Seats: 40T

Converted to S&T Staff & Dormitory Coach in 1959

3107 **86072** KDE320759 Bere Ferrers Station Museum, Devon

### **ARTICULATED SUBURBAN QUADRUPLETS**

**QUADART**

Diagram: GN467 Built: 1924 Builder: Doncaster Design: Gresley Seats: 336T

Quadart set 74

8861	48861	<b>86384</b>	North Norfolk Railway	Brake Third. Diag:72B. Seats:60T.
8862	48862	<b>86385</b>	North Norfolk Railway	Third. Diag:73. Seats:84T.
8863	48863	<b>86386</b>	North Norfolk Railway	Third. Diag:74. Seats:96T.
8864	48864	<b>86387</b>	North Norfolk Railway	Third. Diag:75. Seats:96T.

### **COMPOSITE with LAVATORY [non-gangwayed]**

**CL**

Diagram: 338 Built: 1947 Builder: Cravens Design: Thompson Seats: 19F, 33T

**88339** RSR Northeast, Spennymoor, County Durham

### **CHIEF ENGINEERS SALOON**

**SALOON**

Diagram: Built: 1936 Builder: Doncaster Design: Gresley

900580 **900580** DE900580 1998 West Coast Railway Company, Carnforth 'LOCH EIL'