

## PASSENGER CARRYING COACHING STOCK

## DYNAMOMETER CAR

## DYNAMOMETER

Lot: 293 Built: 1901 Builder: Swindon Bogied Design: Dean  
 Built under Wagon Lot 293, numbered 790 until 1916

**7 South Devon Railway**

## CORRIDOR THIRD

## TK

Lot: 1623 Diagram: C.77 Built: 1940 Builder: Swindon Bogied Design: Collett Seats: 64T  
 Used as Internal User at Swindon Works

**536 079152 Didcot Railway Centre**

## BRAKE OPEN THIRD

## BTO

Lot: 1644 Diagram: D.130 Built: 1940 Builder: Swindon Bogied Design: Collett Seats: 40T  
**650**

**Severn Valley Railway**

## CORRIDOR THIRD

## TK

Lot: 1691 Diagram: C.82 Built: 1948 Builder: Swindon Bogied Design: Hawksworth Seats: 64T  
 796 converted to a Dynamometer Car in 1961

**796 ADW150192 West Coast Railway Company, Carnforth**  
**829 Severn Valley Railway**

Lot: 1593 Diagram: C.77 Built: 1938 Builder: Swindon Bogied Design: Collett Seats: 64T  
 Used as Internal Users at Swindon Works

**1086 079154 Severn Valley Railway**

**1087 079158 Severn Valley Railway**

**1111 079159 Didcot Railway Centre**

**1116 079157 Severn Valley Railway**

**1146 079153 Severn Valley Railway**

## OPEN THIRD

## TO

Lot: 1575 Diagram: C.74 Built: 1937 Builder: Swindon Bogied Design: Collett Seats: 64T  
**1285**

**South Devon Railway**

**1289 Didcot Railway Centre**

**1295 South Devon Railway**

## THIRD [non-gangwayed]

## T

Lot: 1038 Diagram: C.22 Built: 1903 Builder: Swindon Bogied Design: Dean  
**1357 DW14571 Didcot Railway Centre**

## BRAKE CORRIDOR THIRD

## BTK

Lot: 1594 Diagram: D.127 Built: 1938 Builder: Swindon Bogied Design: Collett Seats: 32T  
 Used as Internal User at Newton Abbot

**1649 079170 South Devon Railway**

## THIRD [non-gangwayed]

## T

Lot: 962 Diagram: C.10 Built: 1901 Builder: Swindon Bogied Design: Dean  
**1941 DW14198 Didcot Railway Centre**

## CORRIDOR THIRD

## TK

Lot: 1720 Diagram: C.82 Built: 1949 Builder: Swindon Bogied Design: Hawksworth Seats: 64T  
**2119**

**Severn Valley Railway**

## BRAKE CORRIDOR THIRD

## BTK

Lot: 1732 Diagram: D.133 Built: 1950 Builder: Swindon Bogied Design: Hawksworth Seats: 32T  
 2180, 2216, 2225, 2232 & 2233 converted to CCE Staff & Dormitory Coaches in 1967/68

**2180 DW150405 South Devon Railway**

**2202 Didcot Railway Centre**

**2216 DW150402 Llangollen Railway**

**2225 DW150392 Cholsey & Wallingford Railway**

**2232 DW150397 Didcot Railway Centre**

**2233 DW150401 Severn Valley Railway**

Lot: 1744 Diagram: D.133 Built: 1951 Builder: Swindon Bogied Design: Hawksworth Seats: 32T  
 Converted to CCE Staff & Dormitory Coach in 1967

**2242 DW150391 Severn Valley Railway**

Lot: 1174 Diagram: D.46 Built: 1911 Builder: Swindon Bogied Design: Churchward Seats: 32T

Converted to Track Recording Coach in 1930						
<b>2360</b>	DW139	<b>Barry Tourist Railway</b>			'Whitewash Coach'	
Lot: 1180	Diagram: D.47	Built: 1911	Builder: Swindon	Bogied	Design: Churchward	Seats: 32T
Converted to BTU Tool Van in 1955						
<b>2370</b>	ADW309	<b>The Station Kitchen, West Bay, Dorset</b>				
<b>CORRIDOR THIRD</b>						<b>TK</b>
Lot: 1167	Diagram: C.30	Built: 1910	Builder: Swindon	Bogied	Design: Churchward	Seats: 64T
2426 converted to Camping Coach in 1952. 2434 converted to Staff & Dormitory Coach in 1956.						
<b>2426</b>	9918	<b>Severn Valley Railway</b>				
<b>2434</b>	DW150038	<b>Bodmin Steam Railway</b>				
Lot: 1172	Diagram: C.31	Built: 1911	Builder: Swindon	Bogied	Design: Churchward	Seats: 64T
Converted to BTU Staff Coach in 1956						
<b>2447</b>	ADW150019	<b>Doldowlod Caravan Park, near Rhayader, Powys</b>				
Lot: 1234	Diagram: C.32	Built: 1914	Builder: Swindon	Bogied	Design: Churchward	Seats: 64T
Converted to Camping Coaches in 1957/58						
<b>2573</b>	9879	<b>West Somerset Railway</b>			'CAROL'	
<b>2578</b>	9889	<b>West Somerset Railway</b>				
Lot: 1098	Diagram: C.24	Built: 1905	Builder: Swindon	Bogied	Design: Churchward	Seats: 72T
Used as Internal User at Newquay						
<b>3299</b>	079002	<b>Didcot Railway Centre</b>				
Lot: 1286	Diagram: C.32	Built: 1921	Builder: Swindon	Bogied	Design: Churchward	Seats: 64T
Rebuild of 3939, lot 1246 of 1915. Converted to Camping Coach in 1958.						
<b>3631</b>	9880	<b>West Somerset Railway</b>			'FLORENCE'	
Lot: 1289	Diagram: C.31	Built: 1921	Builder: Swindon	Bogied	Design: Churchward	Seats: 64T
Rebuild of 24xx, lot 11xx of 1910. Converted to Camping Coach in 1957.						
<b>3639</b>	9887	<b>West Somerset Railway</b>				
Lot: 1295	Diagram: C.35	Built: 1921	Builder: Swindon	Bogied	Design: Churchward	Seats: 64T
Rebuild of 3xxx, lot 12xx of 1917. Converted to Camping Coach in 1957.						
<b>3665</b>	9886	<b>West Somerset Railway</b>			'BERYL'	
Lot: 1313	Diagram: C.35	Built: 1922	Builder: Swindon	Bogied	Design: Churchward	Seats: 64T
Rebuild of 3xxx, lot 12xx of 1917. Converted to Camping Coach in 1957.						
<b>3668</b>	9888	<b>West Somerset Railway</b>				
<b>BRAKE THIRD [non-gangwayed]</b>						<b>BT</b>
Lot: 1275	Diagram: D.62	Built: 1921	Builder: Swindon	Bogied	Design: Churchward	Seats: 60T
<b>3755</b>		<b>Didcot Railway Centre</b>				
<b>3756</b>		<b>Didcot Railway Centre</b>				
<b>CORRIDOR THIRD</b>						<b>TK</b>
Lot: 1269	Diagram: C.32	Built: 1920	Builder: Swindon	Bogied	Design: Churchward	Seats: 64T
Converted to Camping Coaches in 1958						
<b>3885</b>	3385 9882	<b>West Somerset Railway</b>			'HILDA'	
<b>3898</b>	9884	<b>Swindon &amp; Cricklade Railway</b>				'FREDA'
Lot: 1246	Diagram: C.32	Built: 1915	Builder: Swindon	Bogied	Design: Churchward	Seats: 64T
3917 converted to a Camping Coach in 1958. 3930 converted to CCE Staff & Dormitory Coach in 1956.						
<b>3917</b>	9883	<b>Llangollen Railway</b>			Numbered 3719 'GRACE'	
<b>3930</b>	DW150011	<b>Severn Valley Railway</b>				
Lot: 1256	Diagram: C.35	Built: 1919	Builder: Swindon	Bogied	Design: Churchward	Seats: 64T
Converted to Camping Coaches in 1957/58						
<b>3963</b>	9885	<b>Didcot Railway Centre</b>			'ALICE'	
<b>3980</b>	9881	<b>West Somerset Railway</b>				'ELSIE'
Lot: 1352	Diagram: C.54	Built: 1925	Builder: Swindon	Bogied	Design: Collett	Seats: 64T
Converted to S&T Dormitory Coaches in 1959. KDW150205 subsequently used as Internal User at Westbourne Park.						
<b>4546</b>	KDW150205 060903	<b>West Somerset Railway</b>				
<b>4553</b>	KDW150207	<b>Didcot Railway Centre</b>				
Lot: 1369	Diagram: C.54	Built: 1926	Builder: Swindon	Bogied	Design: Collett	Seats: 64T
Converted to S&T Dormitory Coaches in 1959. KDW150205 subsequently used as Internal User at St.Austell Goods Yard and Exeter Red Cow Crossing.						
<b>4777</b>	KDW150206 060907	<b>Quinton Rail Technology Centre, Long Marston</b>				
<b>4786</b>	KDW150208	<b>Severn Valley Railway</b>				

Lot: 1372	Diagram: C.54	Built: 1927	Builder: Swindon	Bogied	Design: Collett	Seats: 64T
Converted to S & T Dormitory Coach in 1959.						
<b>4872</b>	KDW150209	<b>South Devon Railway</b>				
Lot: 1383	Diagram: C.54	Built: 1928	Builder: Swindon	Bogied	Design: Collett	Seats: 64T
5043 converted to a BTU Staff Coach in 1963. 5085 converted to a S&T Dormitory Coach in 1959.						
<b>5043</b>	ADW150301	<b>Severn Valley Railway</b>				
<b>5085</b>	KDW150200	<b>Didcot Railway Centre</b>				
<b>BRAKE CORRIDOR THIRD</b>						<b>BTK</b>
Lot: 1384	Diagram: D.95	Built: 1928	Builder: Swindon	Bogied	Design: Collett	Seats: 32T
Converted to a CCE Staff & Tool Coaches in 1959.						
<b>5102</b>	DW150234	<b>Llangollen Railway</b>				
<b>5131</b>	DW150246	<b>West Somerset Railway</b>				
<b>BRAKE THIRD [non-gangwayed]</b>						<b>BT</b>
Lot: 1493	Diagram: D.117	Built: 1934	Builder: Swindon	Bogied	Design: Collett	Seats: 50T
Used as Internal User at Newport Docks						
<b>5500</b>	071343	<b>Railway Support Services, Rye Farm, Wishaw</b>				
Lot: 1392	Diagram: D.101	Built: 1928	Builder: Swindon	Bogied	Design: Collett	Seats: 50T
Converted to BTU Staff Coach in 1962						
<b>5539</b>	DW150328	<b>Railway Support Services, Rye Farm, Wishaw</b>				
<b>BRAKE CORRIDOR THIRD</b>						<b>BTK</b>
Lot: 1490	Diagram: D.116	Built: 1933	Builder: Swindon	Bogied	Design: Collett	Seats: 32T
Used as Internal User at Bristol						
<b>5787</b>	079089	<b>Didcot Railway Centre</b>				
Lot: 1510	Diagram: D.118	Built: 1934	Builder: Swindon	Bogied	Design: Collett	Seats: 32T
Converted to BTU Tool Van in 1963						
<b>5804</b>	3406 ADW150304	<b>Severn Valley Railway</b>	Part of Ambulance Train 34 (1943-1946)			
<b>CORRIDOR THIRD</b>						<b>TK</b>
Lot: 1509	Diagram: C.67	Built: 1935	Builder: Swindon	Bogied	Design: Collett	Seats: 64T
Converted to Emergency Control Train Coaches in 1957/62						
<b>5813</b>	TDW150324	<b>Dean Forest Railway</b>				
<b>5856</b>	TDW150031	<b>West Somerset Railway</b>				
<b>5863</b>	TDW150325	<b>Dean Forest Railway</b>				
<b>BRAKE CORRIDOR THIRD</b>						<b>BTK</b>
Lot: 1514	Diagram: D.118	Built: 1934	Builder: Swindon	Bogied	Design: Collett	Seats: 32T
Used as Internal User at Briton Ferry						
<b>5883</b>	079135	<b>Severn Valley Railway</b>				
<b>CORRIDOR THIRD</b>						<b>TK</b>
Lot: 1527	Diagram: C.67	Built: 1935	Builder: Swindon	Bogied	Design: Collett	Seats: 64T
<b>5952</b>		<b>Didcot Railway Centre</b>				
<b>CORRIDOR COMPOSITE</b>						<b>CK</b>
Lot: 1382	Diagram: E.132	Built: 1928	Builder: Swindon	Bogied	Design: Collett	Seats: 24F,24T
Converted to BTU Staff & Dormitory Coach in 1962.						
<b>6045</b>	DW150293	<b>Severn Valley Railway</b>				
<b>INSPECTION SALOON</b>						<b>SALOON</b>
Lot: 1170	Diagram: Q.1	Built: 1910	Builder: Swindon	Bogied	Design: Churchward	Seats: 12U
Built on underframe of Manchester & Milford Railway Composite 149, GWR 7900.						
<b>6479</b>	80977	<b>Pontypool &amp; Blaenavon Railway</b>				
<b>BRAKE CORRIDOR COMPOSITE</b>						<b>BCK</b>
Lot: 1350	Diagram: E.128	Built: 1926	Builder: Swindon	Bogied	Design: Collett	Seats: 12F,32T
Converted to S&T Staff & Tool Coach in 1961						
<b>6515</b>	KDW150270	<b>South Devon Railway</b>				
Lot: 1589	Diagram: E.159	Built: 1938	Builder: Swindon	Bogied	Design: Collett	Seats: 12F,32T
<b>6562</b>		<b>Severn Valley Railway</b>				
<b>6705</b>		<b>West Somerset Railway</b>				
Lot: 1508	Diagram: E.148	Built: 1934	Builder: Swindon	Bogied	Design: Collett	Seats: 12F,32T

Used as Internal User at Radyr

**6913** 079134 **Severn Valley Railway**

### TRI-COMPOSITE (slip coach)

### TRI-COMPOSITE

Lot: 890 Diagram: F.12 Built: 1898 Builder: Swindon Bogied Design: Dean

Numbered 1091 until 1907

**7091** **St.Germans Station, Cornwall** Body only remains on replica u/f

### CORRIDOR COMPOSITE

### CK

Lot: 1639 Diagram: E.162 Built: 1941 Builder: Swindon Bogied Design: Collett Seats: 24F,24T

7284 used as Internal User at Swindon Works

**7284** 079156 **Severn Valley Railway**

**7285** **Didcot Railway Centre**

Lot: 1621 Diagram: E.158 Built: 1940 Builder: Swindon Bogied Design: Collett Seats: 24F,24T

Used as Internal User at Swindon Works

**7313** 079155 **Didcot Railway Centre**

### BRAKE CORRIDOR COMPOSITE

### BCK

Lot: 1640 Diagram: E.159 Built: 1941 Builder: Swindon Bogied Design: Collett Seats: 12F,32T

7362 used as Internal User at Swindon Works

**7362** 079151 **Dean Forest Railway**

**7371** **Didcot Railway Centre**

Lot: 1690 Diagram: E.164 Built: 1948 Builder: Swindon Bogied Design: Hawksworth Seats: 12F,32T

Royal Train Coaches

**7372** **Didcot Railway Centre**

**7377** **South Devon Railway**

Lot: 1138 Diagram: E.83 Built: 1907 Builder: Swindon Bogied Design: Churchward Seats: 12F,32T

Originally Brake Corridor Tri-Composites seating 12F,12S,16T. 7538 converted to a BTU Staff Coach in 1956. 7545 converted for S&T use in 1957, subsequently used as an

Internal User at various locations on the BR Western Region.

**7538** DW150020 **West Somerset Railway**

**7545** KDW7545 079076 **Swindon & Cricklade Railway**

### CORRIDOR COMPOSITE

### CK

Lot: 1171 Diagram: E.88 Built: 1911 Builder: Swindon Bogied Design: Churchward Seats: 24F,24T

Converted to S&T Staff and Tool Van in 1955

**7740** KDW317 **West Somerset Railway**

### BRAKE CORRIDOR COMPOSITE

### BCK

Lot: 1323 Diagram: E.114 Built: 1923 Builder: Swindon Bogied Design: Collett Seats: 12F,32T

Used as Internal User at Exeter

**7976** 079027 **Didcot Railway Centre**

### LUGGAGE CORRIDOR COMPOSITE

### CK(L)

Lot: Diagram: E. ? Built: 189x Builder: Swindon Bogied Design: Dean Seats: ??F,??T

**7xxx** **Erwood Station Craft Centre & Museum, Powys** Body only remains

### FIRST CLASS SALOON

### SALOON

Lot: 804 Diagram: G.31 Built: 1896 Builder: Swindon Bogied Design: Dean

Numbered 231 before 1907. Converted to Civil Engineer's Saloon in 1941.

**8231** 9035 80971 **Pontypool & Blaenavon Railway**

Lot: 840 Diagram: G.4 Built: 1897 Builder: Swindon Bogied Design: Dean

Numbered 233/234 before 1907

**8233** 9002 **Steam - Museum of The G.W.R., Swindon** Body only remains on u/f of BR MK 1 BSK 34626

**8234** 9003 **St.Germans Station, Cornwall** Body only remains on u/f of BR MK 1 BSK 34832 (745282)

### FIRST CLASS SLEEPING CAR

### SLF

Lot: 787 Diagram: J.5 Built: 1897 Builder: Swindon Bogied Design: Dean

Eight berths. Numbered 242 until 1907. Restored with underframe from GWR BCK 6912 - 079133.

**8242** 9038 **West Somerset Railway**

### DIRECTOR'S SALOON

### SALOON

Lot: 745 Diagram: G.3 Built: 1894 Builder: Swindon Bogied Design: Dean Seats: 24F

Numbered 249 before 1907. Converted to Civil Engineer's Saloon in 1940.

**8249** 9045 80978 **South Devon Railway**

### FIRST CLASS RESTAURANT (with Kitchen)

### RFK

Lot: 801	Diagram: H.2	Built: 1896	Builder: Swindon	Bogied	Design: Dean	Seats: 16F
Numbered 250 until 1907						
<b>8250</b>	9501	<b>St.Germans Station, Cornwall</b>		Body only remains on u/f of SR BTK 3204		
<b>SPECIAL SALOON</b>						<b>SALOON</b>
Lot: 1626	Diagram: G.62	Built: 1940	Builder: Swindon	Bogied	Design: Collett	Seats: 24F
6-wheel bogies						
<b>9001</b>	<b>Buckinghamshire Railway Centre</b>					
<b>9002</b>	<b>Didcot Railway Centre</b>					
<b>FIRST CLASS SALOON</b>						<b>SALOON</b>
Lot: 1431	Diagram: G.59	Built: 1930	Builder: Swindon	Bogied	Design: Collett	Seats: 20F
9004 converted to BR North Eastern Region Chief Civil Engineer's Saloon in 1963. 9005 used as BR Western Region General Manager's Saloon.						
<b>9004</b>	DE321011	<b>L&amp;NWR Heritage Company, Crewe</b>				
<b>9005</b>	<b>One:One Collection, Margate, Kent</b>					
<b>ROYAL SALOON</b>						<b>ROYAL</b>
Lot: 1673	Diagram: G.64	Built: 1945	Builder: Swindon	Bogied	Design: Collett	Seats: 15
6-wheel bogies. Built on underframe of 1133, lot 1593, diagram C.77 of 1938. Contains two bedrooms, a bathroom, seating saloon, dining room, attendant's sleeping compartment and kitchen.						
<b>9006</b>	<b>West Coast Railway Company, Carnforth</b>					
Lot: 1673	Diagram: G.65	Built: 1945	Builder: Swindon	Bogied	Design: Collett	Seats: 7
6-wheel bogies. Built on underframe of 1598, lot 1574, diagram D.124 of 1937. Contains lounge, two large bedrooms and guards compartment.						
<b>9007</b>	<b>West Coast Railway Company, Carnforth</b>			National Collection		
<b>FIRST CLASS SALOON</b>						<b>SALOON</b>
Lot: 241	Diagram: G.2	Built: 1881	Builder: Swindon	Bogied	Design: Dean	
Numbered 248 until 1907. Converted to Civil Engineer's Saloon in 1936.						
<b>9044</b>	80973	<b>Bodmin Steam Railway</b>		'MADAME PATIE'		
Lot: 1209	Diagram: G.43	Built: 1912	Builder: Swindon	Bogied	Design: Churchward	Seats: 50F
Converted to Mobile Work Study Office in 1957						
<b>9055</b>	DW150127	<b>Severn Valley Railway</b>				
<b>FIRST CLASS SLEEPING CAR</b>						<b>SLF</b>
Lot: 1702	Diagram: J.18	Built: 1951	Builder: Swindon	Bogied	Design: Hawksworth	
6-wheel bogies, ten berths						
<b>9082</b>	<b>Peak Railway, Darley Dale</b>					
<b>9083</b>	<b>Didcot Railway Centre</b>					
<b>9084</b>	<b>Severn Valley Railway</b>					
<b>9085</b>	<b>Severn Valley Railway</b>					
<b>THIRD CLASS SALOON</b>						<b>SALOON</b>
Lot: 1400	Diagram: G.58	Built: 1929	Builder: Swindon	Bogied	Design: Collett	Seats: 44T
Used as Internal User at Danygraig						
<b>9103</b>	079124	<b>Severn Valley Railway</b>				
<b>SUPER SALOON</b>						<b>SALOON</b>
Lot: 1471	Diagram: G.60	Built: 1932	Builder: Swindon	Bogied	Design: Collett	Seats: 29F
<b>9111</b>	<b>South Devon Railway</b>			'KING GEORGE'		
<b>9112</b>	<b>Didcot Railway Centre</b>			'QUEEN MARY'		
Lot: 1471	Diagram: G.61	Built: 1932	Builder: Swindon	Bogied	Design: Collett	Seats: 29F
9118 Rebuilt with a Kitchen Diag. H.51						
<b>9113</b>	<b>Didcot Railway Centre</b>			'PRINCE OF WALES'		
<b>9116</b>	<b>South Devon Railway</b>			'DUCHESS OF YORK'		
<b>9118</b>	<b>Didcot Railway Centre</b>			'PRINCESS ELIZABETH'		
<b>NONDESCRIPT SALOON</b>						<b>UO</b>
Lot: 1250	Diagram: G.56	Built: 1923	Builder: Swindon	Bogied	Design: Churchward	Seats: 44U
Converted to Mobile Work Study Office in 1957						
<b>9369</b>	DW150128	<b>Severn Valley Railway</b>				
<b>COMPOSITE RESTAURANT (with Kitchen)</b>						<b>RCK</b>
Lot: 1010	Diagram: H.7	Built: 1902	Builder: Swindon	Bogied	Design: Dean	Seats: ??F,??T
Numbered 1580 prior to 1907. Restored with underframe from GWR TK 3655.						
<b>9520</b>	<b>Didcot Railway Centre</b>					

Lot: 1349      Diagram: H.33      Built: 1925      Builder: Swindon      Bogied      Design: Collett      Seats: 12F,24T

Converted to Western Region S&T Managers Saloon in 1961

**9580**      KDW150266      **East Lancashire Railway**

**FIRST CLASS RESTAURANT (with Kitchen)**

**RFK**

Lot: 1468      Diagram: H.39      Built: 1932      Builder: Swindon      Bogied      Design: Collett      Seats: 23F

Converted to Mobile Work Study Office in 1962

**9615**      DW150336      **Severn Valley Railway**

**THIRD CLASS RESTAURANT**

**RTO**

Lot: 1469      Diagram: H.40      Built: 1932      Builder: Swindon      Bogied      Design: Collett      Seats: 63T

Used as Internal User at Roath Docks

**9627**      079112      **Severn Valley Railway**

**UNCLASSIFIED RESTAURANT BUFFET (with**

**RUKB**

Lot: 1518      Diagram: H.41      Built: 1934      Builder: Swindon      Bogied      Design: Collett      Seats: 12U

**9631**      **Steam - Museum of The G.W.R., Swindon**

National Collection

**FIRST CLASS RESTAURANT**

**RFO**

Lot: 1540      Diagram: H.43      Built: 1935      Builder: Swindon      Bogied      Design: Collett      Seats: 24F

**9635**      **Didcot Railway Centre**

**THIRD CLASS RESTAURANT**

**RTO**

Lot: 1359      Diagram: H.51      Built: 1925      Builder: Swindon      Bogied      Design: Collett      Seats: 63T

Built as articulated stock. 9653 is a rebuild of 10020, diagram H.32. 9654 is a rebuild of 10036, diagram H.32. Converted to Emergency Control Train Coaches in 1957/62.

**9653**      TDW150032      **Severn Valley Railway**

National Collection

**9654**      TDW150326      **Severn Valley Railway**

**INSPECTION SALOON**

**SALOON**

Lot: 1701      Diagram: Q.13      Built: 1948      Builder: Swindon      Bogied      Design: Hawksworth      Seats: 23U

**80943**      **Dean Forest Railway**

**80969**      **Severn Valley Railway**

**80970**      DW80970      **Great Central Railway**

**80972**      **Severn Valley Railway**

**80974**      **North Yorkshire Moors Railway**

**80975**      DW80975      **Llangollen Railway**

**80976**      TDW80976      **West Somerset Railway**

# NON-PASSENGER CARRYING COACHING STOCK

## PASSENGER BRAKE, GANGWAYED

**BG**

Lot: 1667      Diagram: K.44      Built: 1941      Builder: Swindon      Bogied      Design: Collett  
**64**                **The Old Post House, Blakemere**

Lot: 1665      Diagram: K.42      Built: 1945      Builder: Swindon      Bogied      Design: Collett  
**98**                **Severn Valley Railway**

Lot: 1512      Diagram: K.41      Built: 1934      Builder: Swindon      Bogied      Design: Collett  
 Used as Internal User at Reading  
**111**      060790      **Didcot Railway Centre**

Lot: 1535      Diagram: K.41      Built: 1935      Builder: Swindon      Bogied      Design: Collett  
 Converted for use as Seat Storage Vans in 1971  
**184**      ADB975157      **Cholsey & Wallingford Railway**  
**185**      ADB975158      **Gloucestershire-Warwickshire Railway**

Lot: 1281      Diagram: K.22      Built: 1922      Builder: Swindon      Bogied      Design: Churchward  
 Used by British Steel at Llanwern Steel Works  
**261**                **Severn Valley Railway**

Lot: 1665      Diagram: K.42      Built: 1945      Builder: Swindon      Bogied      Design: Collett  
 Converted to BTU Tool Van in 1977  
**276**      ADB975640      **South Devon Railway**

Lot: 1722      Diagram: K.45      Built: 1949      Builder: Swindon      Bogied      Design: Hawksworth  
 Converted to Exhibition Train Generator Van in 1963  
**297**      ZDW150354      **Northampton & Lamport Railway**

Lot: 1740      Diagram: K.45      Built: 1950      Builder: Swindon      Bogied      Design: Hawksworth  
**316**                **Didcot Railway Centre**

Lot: 1752      Diagram: K.46      Built: 1951      Builder: Swindon      Bogied      Design: Hawksworth  
 334 converted to a Camping Coach after preservation.  
**333**                **Didcot Railway Centre**  
**334**                **North Yorkshire Moors Railway**      Camping Coach 172

## POST OFFICE STOWAGE VAN

**POT**

Lot: 1666      Diagram: L.23      Built: 1940      Builder: Swindon      Bogied      Design: Collett  
 Replacement Coach. Converted for use as an Enparts Van in 1971.  
**814**      ADB975156      **Didcot Railway Centre**

Lot: 465      Diagram: L.3      Built: 1889      Builder: Swindon      Bogied      Design: Dean  
 Built as Post Office Sorting Van (POS) with broad gauge bogies and numbered 599, bogies replaced with standard gauge bogies in 1891 and renumbered 2086. Converted to Post Office Stowage Van 1896, diagram L.12, modified to diagram L.3 in 1909.  
**841**                **St.Germans Station, Cornwall**

## PASSENGER BRAKE [non-gangwayed]

**B**

Lot: 883      Diagram: K.14      Built: 1903      Builder: Swindon      Bogied      Design: Dean  
 Used as Internal User at Hockley Goods Depot, Birmingham  
**933**      064094      **Didcot Railway Centre**

## PASSENGER BRAKE, GANGWAYED

**BG**

Lot: 1301      Diagram: K.22      Built: 1922      Builder: Swindon      Bogied      Design: Churchward  
 1145 used as Internal User at Bristol. 1150 converted to CCE Drying Van in 1960.  
**1145**      079038      **Severn Valley Railway**  
**1150**      DW150241      **Vale of Berkeley Railway, Sharpness**      Stored at Berkeley Power Station

Lot: 1344      Diagram: K.36      Built: 1925      Builder: Swindon      Bogied      Design: Churchward  
 Converted to Medical Examination Coach in January 1945, Freight lot 1481, carriage diagram M.33. Renumbered into Departmental Stock in 1961.  
**1159**      DW150294      **Didcot Railway Centre**

Lot: 1413      Diagram: K.40      Built: 1930      Builder: Swindon      Bogied      Design: Collett  
**1184**                **Didcot Railway Centre**

## AUTO-TRAILERS

### AUTO-TRAILER

Lot: 1126      Diagram: N      Built: 1907      Builder: Swindon

Used as Internal User at Cardiff Canton Depot

**38**      079022      **Telford Steam Railway**

Bogied      Design: Churchward

Seats: 64T

Lot: 1198      Diagram: U      Built: 1912      Builder: Swindon

**92**      **Didcot Railway Centre**

Bogied      Design: Churchward

Seats: 70T

Lot: 1394      Diagram: A.27      Built: 1929      Builder: Swindon

163 converted to Work Study Coach in 1962. 167 & 169 used as Internal Users at Gloucester Depot

**163**      ADW150315      **Llangollen Railway**

**167**      079050      **Llangollen Railway**

**169**      064749      **West Somerset Railway**

Bogied      Design: Collett

Seats: 64T

Lot: 1410      Diagram: A.28      Built: 1930      Builder: Swindon

174 converted to Staff Coach in 1962.

**174**      TDW150313      **Llangollen Railway**

**178**      **Severn Valley Railway**

Bogied      Design: Collett

Seats: 64T

Lot: 1480      Diagram: A.30      Built: 1933      Builder: Swindon

Used as Internal User at ?

**190**      079052      **Didcot Railway Centre**

Bogied      Design: Collett

Seats: 64T

Lot: 1736      Diagram: A.38      Built: 1951      Builder: Swindon

233 converted to CM&EE Test Car 1 in 1966.

**225**      **South Devon Railway**

**228**      **South Devon Railway**

**231**      **Didcot Railway Centre**

**232**      **Bodmin Steam Railway**

**233**      ADW150375      **South Devon Railway**

Bogied      Design: Hawksworth

Seats: 64T

'Clare'

Lot: 1766      Diagram: A.43      Built: 1954      Builder: Swindon

**238**      **Severn Valley Railway**

**240**      **South Devon Railway**

Bogied      Design: Hawksworth

Seats: 64T

'Charlotte'

### AUTO-TRAILER